

TOSHIBA

AIR CONDITIONER (SPLIT TYPE) Installation Manual



1116950172


Indoor Unit

Model name:

For commercial use

Concealed Duct High Static Pressure Type

RAV-SH6001BP Series RAV-SH6001BTP Series



Original instruction

- Please read this Installation Manual carefully before installing the Air Conditioner.
- This Manual describes the installation method of the indoor unit.
 - For installation of the outdoor unit, follow the Installation Manual attached to the outdoor unit.
 - For precaution for safety, follow the Installation Manual attached to the outdoor unit.

ADOPTION OF NEW REFRIGERANT

This Air Conditioner uses R410A an environmentally friendly refrigerant.

Contents

1	Precautions for safety	3
2	Accessory parts	8
3	Selection of installation place	8
4	Installation	10
5	Drain piping	11
6	Duct design	13
7	Refrigerant piping	14
8	Electrical connection	16
9	Applicable controls	18
10	Test run	23
11	Maintenance	23
12	Troubleshooting	24

Thank you for purchasing this Toshiba air conditioner.

Please read carefully through these instructions that contain important information which complies with the Machinery Directive (Directive 2006/42/EC), and ensure that you understand them. After completing the installation work, hand over this Installation Manual as well as the Owner's Manual provided to the user, and ask the user to keep them in a safe place for future reference.

Generic Denomination: Air Conditioner

Definition of Qualified Installer or Qualified Service Person

The air conditioner must be installed, maintained, repaired and removed by a qualified installer or qualified service person. When any of these jobs is to be done, ask a qualified installer or qualified service person to do them for you. A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the following table.

Agent	Qualifications and knowledge which the agent must have
Qualified installer	<ul style="list-style-type: none"> The qualified installer is a person who installs, maintains, relocates and removes the air conditioners made by Toshiba Carrier Corporation. He or she has been trained to install, maintain, relocate and remove the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. The qualified installer who is allowed to do the electrical work involved in installation, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified installer who is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified installer who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.
Qualified service person	<ul style="list-style-type: none"> The qualified service person is a person who installs, repairs, maintains, relocates and removes the air conditioners made by Toshiba Carrier Corporation. He or she has been trained to install, repair, maintain, relocate and remove the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified service person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified service person who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.

Definition of Protective Gear

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.

In addition to such normal protective gear, wear the protective gear described below when undertaking the special work detailed in the following table.

Failure to wear the proper protective gear is dangerous because you will be more susceptible to injury, burns, electric shocks and other injuries.

Work undertaken	Protective gear worn
All types of work	Protective gloves 'Safety' working clothing
Electrical-related work	Gloves to provide protection for electricians and from heat Insulating shoes Clothing to provide protection from electric shock
Work done at heights (50 cm or more)	Helmets for use in industry
Transportation of heavy objects	Shoes with additional protective toe cap
Repair of outdoor unit	Gloves to provide protection for electricians and from heat

These safety cautions describe important matters concerning safety to prevent injury to users or other people and damages to property. Please read through this manual after understanding the contents below (meanings of indications), and be sure to follow the description.

Indication	Meaning of Indication
 WARNING	Text set off in this manner indicates that failure to adhere to the directions in the warning could result in serious bodily harm (*1) or loss of life if the product is handled improperly.
 CAUTION	Text set off in this manner indicates that failure to adhere to the directions in the caution could result in slight injury (*2) or damage (*3) to property if the product is handled improperly.

*1: Serious bodily harm indicates loss of eyesight, injury, burns, electric shock, bone fracture, poisoning, and other injuries which leave aftereffect and require hospitalization or long-term treatment as an outpatient.


*2: Slight injury indicates injury, burns, electric shock, and other injuries which do not require hospitalization or long-term treatment as an outpatient.

*3: Damage to property indicates damage extending to buildings, household effects, domestic livestock, and pets.

■ Center of gravity

(Unit: mm)

Use forklift to carry in the air conditioner units and use winch or hoist at installation of them.



■ Warning indications on the air conditioner unit

Warning indication	Description
 <p>WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.</p>	<p>WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.</p>
 <p>WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.</p>	<p>WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.</p>
 <p>CAUTION High temperature parts. You might get burned when removing this panel.</p>	<p>CAUTION High temperature parts. You might get burned when removing this panel.</p>
 <p>CAUTION Do not touch the aluminum fins of the unit. Doing so may result in injury.</p>	<p>CAUTION Do not touch the aluminium fins of the unit. Doing so may result in injury.</p>
 <p>CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.</p>	<p>CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.</p>

1 Precautions for safety

The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual.

WARNING

General

- Before starting to install the air conditioner, read through the Installation Manual carefully, and follow its instructions to install the air conditioner.
- Only a qualified installer or service person is allowed to do installation work. Inappropriate installation may result in water leakage, electric shock or fire.
- Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.
- Before opening the electrical control box cover of the indoor unit or service panel of the outdoor unit, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer(*1) or qualified service person(*1) is allowed to remove the electrical control box cover of the indoor unit or service panel of the outdoor unit and do the work required.
- Before carrying out the installation, maintenance, repair or removal work, be sure to set the circuit breaker to the OFF position. Otherwise, electric shocks may result.
- Place a “Work in progress” sign near the circuit breaker while the installation, maintenance, repair or removal work is being carried out. There is a danger of electric shocks if the circuit breaker is set to ON by mistake.
- Only a qualified installer(*1) or qualified service person(*1) is allowed to undertake work at heights using a stand of 50 cm or more or to remove the intake grille of the indoor unit to undertake work.

- Wear protective gloves and safety work clothing during installation, servicing and removal.
- Do not touch the aluminum fin of the outdoor unit. You may injure yourself if you do so. If the fin must be touched for some reason, first put on protective gloves and safety work clothing, and then proceed.
- Before opening the suction board cover, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in injury through contact with the rotation parts. Only a qualified installer(*1) or qualified service person(*1) is allowed to remove the suction board cover and do the work required.
- When work is performed at heights, use a ladder which complies with the ISO 14122 standard, and follow the procedure in the ladder's instructions. Also wear a helmet for use in industry as protective gear to undertake the work.
- Before cleaning the filter or other parts of the outdoor unit, set the circuit breaker to OFF without fail, and place a "Work in progress" sign near the circuit breaker before proceeding with the work.
- Before working at heights, put a sign in place so that no one will approach the work location, before proceeding with the work. Parts and other objects may fall from above, possibly injuring a person below. While carrying out the work, wear a helmet for protection from falling objects.
- Do not use the refrigerant other than R410A.
For the refrigerant type, check the outdoor unit to be combined.
- The refrigerant used by this air conditioner, follow to the outdoor unit.
- The air conditioner must be transported in stable condition. If any part of the product is broken, contact the dealer.
- When the air conditioner must be transported by hand, carry it by two or more people.
- Do not move or repair any unit by yourself. There is high voltage inside the unit. You may get electric shock when removing the cover and main unit.
- This appliance is intended to be used by expert or trained users in shops, in light industry, or for commercial use by lay persons.

Selection of installation location

- When the air conditioner is installed in a small room, provide appropriate measures to ensure that the concentration of refrigerant leakage occur in the room does not exceed the critical level.
- Do not install in a location where flammable gas leaks are possible. If the gas leak and accumulate around the unit, it may ignite and cause a fire.
- To transport the air conditioner, wear shoes with additional protective toe caps.
- To transport the air conditioner, do not take hold of the bands around the packing carton. You may injure yourself if the bands should break.
- Install the indoor unit at least 2.5 m above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.
- Do not place any combustion appliance in a place where it is directly exposed to the wind of air conditioner, otherwise it may cause imperfect combustion.

Installation

- When the indoor unit is to be suspended, the designated hanging bolts (M10 or W3/8) and nuts (M10 or W3/8) must be used.
- Install the air conditioner securely in a location where the base can sustain the weight adequately. If the strength is not enough, the unit may fall down resulting in injury.
- Follow the instructions in the Installation Manual to install the air conditioner. Failure to follow these instructions may cause the product to fall down or topple over or give rise to noise, vibration, water leakage or other trouble.
- Carry out the specified installation work to guard against the possibility of high winds and earthquake. If the air conditioner is not installed appropriately, a unit may topple over or fall down, causing an accident.

- If refrigerant gas has leaked during the installation work, ventilate the room immediately. If the leaked refrigerant gas comes in contact with fire, noxious gas may generate.
- Use forklift to carry in the air conditioner units and use winch or hoist at installation of them.
- Suction duct length must be longer than 850 mm.
- Helmet must be worn to protect your head from falling objects. Especially, when you work under an inspection opening, helmet must be worn to protect your head from falling objects from the opening.

Refrigerant piping

- Install the refrigerant pipe securely during the installation work before operating the air conditioner. If the compressor is operated with the valve open and without refrigerant pipe, the compressor sucks air and the refrigeration cycles is over pressurized, which may cause an injury.
- Tighten the flare nut with a torque wrench in the specified manner. Excessive tighten of the flare nut may cause a crack in the flare nut after a long period, which may result in refrigerant leakage.
- After the installation work, confirm that refrigerant gas does not leak. If refrigerant gas leaks into the room and flows near a fire source, such as a cooking range, noxious gas may be generated.
- When the air conditioner has been installed or relocated, follow the instructions in the Installation Manual and purge the air completely so that no gases other than the refrigerant will be mixed in the refrigerating cycle. Failure to purge the air completely may cause the air conditioner to malfunction.
- Nitrogen gas must be used for the airtight test.
- The charge hose must be connected in such a way that it is not slack.

Electrical wiring

- Only a qualified installer(*1) or qualified service person(*1) is allowed to carry out the electrical work of the air conditioner. Under no circumstances must this work be done by an unqualified individual since failure to carry out the work properly may result in electric shocks and/or electrical leaks.
- To connect the electrical wires, repair the electrical parts or undertake other electrical jobs, wear gloves to provide protection for electricians, insulating shoes and clothing to provide protection from electric shocks. Failure to wear this protective gear may result in electric shocks.
- Use wiring that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws. Use of wiring which does not meet the specifications may give rise to electric shocks, electrical leakage, smoking and/or a fire.
- Connect earth wire. (Grounding work)
Incomplete grounding causes an electric shock.
- Do not connect earth wires to gas pipes, water pipes, and lightning conductor or telephone earth wires.
- After completing the repair or relocation work, check that the earth wires are connected properly.
- Install a circuit breaker that meets the specifications in the installation manual and the stipulations in the local regulations and laws.
- Install the circuit breaker where it can be easily accessed by the agent.
- When installing the circuit breaker outdoors, install one which is designed to be used outdoors.
- Under no circumstances the power wire must not be extended. Connection trouble in the places where the wire is extended may give rise to smoking and/or a fire.
- Electrical wiring work shall be conducted according to law and regulation in the community and installation manual. Failure to do so may result in electrocution or short circuit.

Test run

- Before operating the air conditioner after having completed the work, check that the electrical control box cover of the indoor unit and service panel of the outdoor unit are closed, and set the circuit breaker to the ON position. You may receive an electric shock if the power is turned on without first conducting these checks.
- If there is any kind of trouble (such as an error display has appeared, smell of burning, abnormal sounds, the air conditioner fails to cool or heat or water is leaking) has occurred in the air conditioner, do not touch the air conditioner yourself but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking “out of service” near the circuit breaker, for instance) until qualified service person arrives. Continuing to use the air conditioner in the trouble status may cause mechanical problems to escalate or result in electric shocks or other trouble.
- After the work has finished, use an insulation tester set (500V Megger) to check the resistance is 1MΩ or more between the charge section and the non-charge metal section (Earth section). If the resistance value is low, a disaster such as a leak or electric shock is caused at user’s side.
- Upon completion of the installation work, check for refrigerant leaks and check the insulation resistance and water drainage. Then conduct a test run to check that the air conditioner is operating properly.

Explanations given to user

- Upon completion of the installation work, tell the user where the circuit breaker is located. If the user does not know where the circuit breaker is, he or she will not be able to turn it off in the event that trouble has occurred in the air conditioner.
- After the installation work, follow the Owner’s Manual to explain to the customer how to use and maintain the unit.

Relocation

- Only a qualified installer(*1) or qualified service person(*1) is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and/or vibration may result.
 - When carrying out the pump-down work shut down the compressor before disconnecting the refrigerant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air or other gas to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in rupture, injury or other trouble.
-

⚠ CAUTION

New refrigerant air conditioner installation

- **This air conditioner adopts the new HFC refrigerant (R410A) which does not destroy ozone layer.**
- The characteristics of R410A refrigerant are; easy to absorb water, oxidizing membrane or oil, and its pressure is approx. 1.6 times higher than that of refrigerant R22. Accompanied with the new refrigerant, refrigerating oil has also been changed. Therefore, during installation work, be sure that water, dust, former refrigerant, or refrigerating oil does not enter the refrigerating cycle.
- To prevent charging an incorrect refrigerant and refrigerating oil, the sizes of connecting sections of charging port of the main unit and installation tools are changed from those for the conventional refrigerant.
- Accordingly the exclusive tools are required for the new refrigerant (R410A).
- For connecting pipes, use new and clean piping designed for R410A, and please care so that water or dust does not enter.

To disconnect the appliance from main power supply

- This appliance must be connected to the main power supply by means of a switch with a contact separation of at least 3 mm.

The installation fuse (all types can be used) must be used for the power supply line of this conditioner.

(*1) Refer to the "Definition of Qualified Installer or Qualified Service Person."

2 Accessory parts

Part name	Q'ty	Shape	Usage
Installation Manual	1	This manual	(Hand over to customers)
Owner's Manual	1		(Hand over to customers)
Heat insulator	2	 (200×200×6t)	For heat insulation of gas pipe and liquid pipe connecting section
Washer	8		For hanging-down unit
Hose band	1		For connecting drain pipe
Flexible hose	1		For adjusting center of drain pipe
Heat insulator	1	 (220×300×10t)	For heat insulation of drain connecting section
Seal material	3	 (45×45×3t)	For sealing of wire connecting port

3 Selection of installation place

Avoid installing in the following places

Select a location for the indoor unit where the cool or warm air will circulate evenly. Avoid installation in the following kinds of locations.

- Saline area (coastal area)
- Locations with acidic or alkaline atmospheres (such as areas with hot springs, factories where chemicals or pharmaceuticals are made and places where the exhaust air from combustion appliances will be sucked into the unit).
Doing so may cause the heat exchanger (its aluminum fins and copper pipes) and other parts to become corroded.
- Locations with atmospheres with mist of cutting oil or other types of machine oil. Doing so may cause the heat exchanger to become corroded, mists caused by the blockage of the heat exchanger to be generated, the plastic parts to be damaged, the heat insulators to peel off, and other such problems to result.
- Places where iron or other metal dust is present. If iron or other metal dust adheres to or collects on the interior of the air conditioner, it may spontaneously combust and start a fire.
- Locations where vapors from food oils are formed (such as kitchens where food oils are used). Blocked filters may cause the air conditioner's performance to deteriorate, condensation to form, the plastic parts to be damaged, and other such problems to result.
- Locations near obstructions such as ventilation openings or lighting fixtures where the flow of the blown air will be disrupted (a disruption of the air flow may cause the air conditioner's performance to deteriorate or the unit to shut down).
- Locations where an in-house power generator is used for the power supply. The power line frequency and voltage may fluctuate, and the air conditioner may not work properly as a result.
- On truck cranes, ships or other moving conveyances.
The air conditioner must not be used for special applications (such as for storing food, plants, precision instruments or art works).
(The quality of the items stored may be degraded.)
- Locations where high frequencies are generated (by inverter equipment, in-house power generators, medical equipment or communication equipment).
(Malfunctioning or control trouble in the air conditioner or noise may adversely affect the equipment's operation.)
- Locations where there is anything under the unit installed that would be compromised by wetness. (If the drain has become blocked or when the humidity is over 80%, condensation from the indoor unit will drip, possibly causing damage to anything underneath.)
- In the case of the wireless type of system, rooms with the inverter type of fluorescent lighting or locations exposed to direct sunlight.
(The signals from the wireless remote controller may not be sensed.)
- Locations where organic solvents are being used.
- The air conditioner cannot be used for liquefied carbonic acid cooling or in chemical plants.
- Location near doors or windows where the air conditioner may come into contact with high-temperature, high humidity outdoor air.
(Condensation may occur as a result.)
- Locations where special sprays are used frequently.
- Places with poor ventilation.

■ Installation under high-humidity atmosphere

In some cases including the rainy season, especially inside of the ceiling may become high-humidity atmosphere (dew-point temperature: 23°C or higher).

1. Installation to inside of the ceiling with tiles on the roof
 2. Installation to inside of the ceiling with slated roof
 3. Installation to a place where inside of the ceiling is used for pathway to intake the fresh air
 4. Installation to a kitchen
- In the above cases, additionally attach the heat insulator to all positions of the air conditioner, which come to contact with the high-humidity atmosphere. In this case, arrange the side plate (Check port) so that it is easily removed.
 - Apply also a sufficient heat insulation to the duct and connecting part of the duct.


[Reference]	Condensation test conditions
Indoor side:	27°C dry bulb temperature 24°C wet bulb temperature
Air volume:	Low air volume, operation time 4 hours

■ Installation space

(Unit: mm)

Reserve sufficient space required for installation or service work.

Space required for installation and servicing



■ Filter cleaning sign term setting

The lighting term setup of the filter sign (Notification of filter cleaning) of the remote controller can be changed according to the condition of installation.

For setup method, refer to "Filter sign setting" in the Applicable controls of this Manual.


4 Installation

⚠ CAUTION

- Strictly comply with the following rules to prevent damage of the indoor units and human injury.
- Do not put a heavy article on the indoor unit or let a person get on it. (Even units are packaged)
 - Carry in the indoor unit as it is packaged if possible. If carrying in the indoor unit unpacked by necessity, use buffering cloth or other material to not damage the unit.
 - To move the indoor unit, hold the hooking brackets (4 positions) only.
 - Do not apply force to the other parts (such as refrigerant pipe, drain pan, foamed parts, or resin parts).
 - Carry the package by two or more persons, and do not bundle it with plastic band at positions other than specified.
 - To install vibration isolation material to hanging bolts, confirm that it does not increase the unit vibration.

■ External dimensions

(Unit: mm)



■ Installation of hanging bolt

- Consider the piping / wiring after the unit is hung to determine the location of the indoor unit installation and orientation.
- After the location of the indoor unit installation has been determined, install hanging bolts.
- For the dimensions of the hanging bolt pitches, refer to the external view.
- When a ceiling already exists, lay the drain pipe, refrigerant pipe, control wires, and remote controller wires to their connection locations before hanging the indoor unit.

Procure hanging bolts washer and nuts for installing the indoor unit (these are not supplied).

Hanging bolt	M10 or W3/8	4 pieces
Nut	M10 or W3/8	12 pieces
Washer	M10	8 pieces

Installation of hanging bolt

Use M10 hanging bolts (4 pcs, locally procured). Matching to the existing structure, set pitch according to size in the unit external view as shown below.

<p>New concrete slab</p> <p>Install the bolts with insert brackets or anchor bolts.</p> <p>(Blade type bracket) (Slide type bracket) (Pipe hanging anchor bolt)</p>
<p>Steel frame structure</p> <p>Use existing angles or install new support angles.</p> <p>Hanging bolt, Hanging bolt, Support angle</p>
<p>Existing concrete slab</p> <p>Use a hole-in anchors, hole-in plugs, or a hole-in bolts.</p>

■ Installation of outdoor unit


Treatment of ceiling

The ceiling differs according to structure of building.

For details, consult your constructor or interior finish contractor.


In the process after the ceiling board has been removed, it is important to reinforce ceiling foundation (frame) and to keep horizontal level of installed ceiling correctly in order to prevent vibration of ceiling board.

- Attach the nuts and the M10 flat washers to the hanging bolt.
- Put washers at up and down of the hanging bracket of the indoor unit to hang down the indoor unit.
- Check that four sides are horizontal with a level gauge. (Horizontal degree: Within 5 mm)



REQUIREMENT


- Hang the unit in a horizontal position. When unit is hung to slant, it may cause overflow of drainage.
- Install the unit within the dimension according to the figure below.
- Use level gauge to confirm whether the unit is hang horizontally.



■ REQUIREMENT

Removing the cardboard for transportation

- Make sure to remove the protection cardboard for transportation that is inserted in the gap between the top cabinet and the heat exchanger before installing the indoor unit.




5 Drain piping

⚠ CAUTION

Following the Installation Manual, perform the drain piping work so that water is properly drained. Apply a heat insulation so as not to cause a dew condensation. Inappropriate piping work may result in water leakage in the room and wet furniture.

- Provide the indoor drain piping with proper heat insulation.
- Provide the area where the pipe connects to the indoor unit with proper heat insulation. Improper heat insulation will cause condensation to form.
- The drain pipe must be sloping downward (at an angle of 1/100 or more), and do not run the pipe up and down (arched shape) or allow it to form traps. Doing so may cause abnormal sounds.
- Restrict the length of the traversing drain pipe to 20 meters or less. For a long pipe, provide support brackets at intervals of 1.5 to 2 meters to prevent flapping.
- Install the collective piping as shown in the following figure.
- Do not provide any air vents. Otherwise, the drain water will spout, causing water to leak.
- Do not allow any force to be applied to the connection area with the drain pipe.



■ Pipe material, size and insulator

The following materials for piping work and insulating process are locally procured.


Pipe material	Hard vinyl chloride pipe VP25 (Nominal outer diameter 32 mm)
Insulator	Foamed polyethylene foam, thickness: 10 mm or more

■ Connecting drain pipe

Insert flexible drain hose into upper drain pipe of main unit as far as it will go. Fix it with hose band.

REQUIREMENT

Mount the flexible drain hose using the hose band without using adhesive.



■ Drain up


When install the drain pump kit (TCB-DP40DPE) of optional accessory, read the Installation Manual supplied to a drain pump kit.

■ Check the draining

Check if the water can flow out properly during the test run. Also, check if no water leakage from the piping connection port.


REQUIREMENT

- Conduct the drain test even in the heating season.
- If it is before the duct work, pour water into the drain pan through the air outlet.
- If it is after the duct work, remove the access panel and pour water, then conduct the drain check.




■ Heat insulating process

- As shown in the figure, cover the flexible hose and hose band with the attached heat insulator up to the bottom of the indoor unit tightly.
- Cover the drain pipe tightly with a heat insulator procured locally so that it overlaps with the attached heat insulator of the drain connecting section.



■ Connecting method of the duct




⚠ CAUTION

Incomplete heat insulation of the supply air flange and sealing may occur dewing resulted in falling of water drop.

■ Fan characteristics

6001BP, BTP



6 Duct design


■ Duct design

- 1** In order to prevent short circuits, design the duct work so that the intake and discharge openings are not adjacent to each other.
- 2** The indoor unit does not have a built-in air filter.
Always install the air filter (Local procure) in a location that permits easy maintenance, such as behind the intake grille. (If no air filter is installed, dust will collect in the heat exchanger, which may cause the air conditioner to fail or to leak.)

<Overview of duct connection>

NOTE


Parts except air conditioner unit are to be locally procured.



CAUTION

- Do not scratch the inner surface of the flared part when removing burrs.
- Flare processing under the condition of scratches on the inner surface of flare processing part will cause refrigerant gas leak.
- Check that the flared part is not scratched, deformed, stepped, or flattened, and that there are no chips adhered or other problems, after flare processing.
- Do not apply refrigerating machine oil to the flare surface.

- * In case of flaring with the conventional flare tool, pull it out approx. 0.5 mm more than that for R22 to adjust to the specified flare size. The copper pipe gauge is useful for adjusting projection margin size.
- The sealed gas was sealed at the atmospheric pressure so when the flare nut is removed, there will be no "whooshing" sound: This is normal and is not indicative of trouble.
- Use two wrenches to connect the indoor unit pipe.



Work using double spanner

- Use the tightening torque levels as listed in the following table.

Outer dia. of connecting pipe (mm)	Tightening torque (N·m)
6.4	14 to 18
9.5	34 to 42
12.7	49 to 61
15.9	63 to 77
19.1	9.5 to 115

▼ Tightening torque of flare pipe connections
 Incorrect connections may cause not only a gas leak, but also a trouble of the refrigeration cycle. Align the centres of the connecting pipes and tighten the flare nut as far as possible with your fingers. Then tighten the nut with a spanner and torque wrench as shown in the figure.

CAUTION

Tightening with an excessive torque may crack the nut depending on installation conditions.

Evacuation

Perform vacuuming from the charge port of valve of the outdoor unit by using a vacuum pump. For details, follow to the Installation Manual attached to the outdoor unit.

- Do not use the refrigerant sealed in the outdoor unit for evacuation.

REQUIREMENT

For the tools such as charge hose, use those manufactured exclusively for R410A.

Refrigerant amount to be added

For addition of the refrigerant, add refrigerant "R410A" referring to the attached Installation Manual of outdoor unit. Use a scale to charge the refrigerant of specified amount.

REQUIREMENT

- Charging an excessive or too little amount of refrigerant causes a trouble of the compressor. Charge the refrigerant of specified amount.
- A personnel who charged the refrigerant should write down the pipe length and the added refrigerant amount in the F-GAS label of the outdoor unit. It is necessary to fix the the compressor and refrigeration cycle malfunction.

Open the valve fully

Open the valve of the outdoor unit fully. A 4 mm hexagonal wrench is required for opening the valve. For details, refer to the Installation Manual attached to the outdoor unit.

Gas leak check

Check with a leak detector or soap water whether gas leaks or not, from the pipe connecting section or cap of the valve.

REQUIREMENT

Use a leak detector manufactured exclusively for HFC refrigerant (R134a, R410A).


Heat insulation process

Apply heat insulation for the pipes separately at liquid side and gas side.

- For the heat insulation to the pipes at gas side, be sure to use the material with heat-resisting temperature 120°C or higher.
- To use the attached heat insulation pipe, apply the heat insulation to the pipe connecting section of the indoor unit securely without gap.

REQUIREMENT

- Apply the heat insulation to the pipe connecting section of the indoor unit securely up to the root without exposure of the pipe. (The pipe exposed to the outside causes water leak.)
- Wrap heat insulator with its slits facing up (ceiling side).



8 Electrical connection

⚠ WARNING

- Use the specified wires for wiring connect the terminals. Securely fix them to prevent external forces applied to the terminals from affecting the terminals.
Incomplete connection or fixation may cause a fire or other trouble.
- **Connect earth wire. (grounding work)**
Incomplete grounding cause an electric shock.
Do not connect earth wires to gas pipes, water pipes, lightning conductor or telephone earth wires.
- **Appliance shall be installed in accordance with national wiring regulations.**
Capacity shortage of power circuit or incomplete installation may cause an electric shock or a fire.

⚠ CAUTION

- If incorrect / incomplete wiring is carried out, it will cause an electrical fire or smoke.
- Be sure to install an earth leakage breaker that is not tripped by shock.
If an earth leakage breaker is not installed, an electric shock may be caused.
- Use the cord clamps attached to the product.
- Do not damage or scratch the conductive core and inner insulator of power and system interconnection wires when peeling them.
- Use the power cord and system interconnection wire of specified thickness, type, and protective devices required.
- Never connect 220–240V power to the terminal blocks (A, B, etc.) for control wiring.
(Otherwise, the system will fail.)
- Perform the electric wiring so that it does not come to contact with the high-temperature part of the pipe.
The coating may melt resulting in an accident.


REQUIREMENT

- For power supply wiring, strictly conform to the Local Regulation in each country.
- Power supply for indoor unit must be exclusive and separated from the one for outdoor unit.
- For wiring of power supply of the outdoor units, follow the Installation Manual of each outdoor unit.
- After connecting wires to the terminal blocks, provide a trap and fix wires with the cord clamp.
- Run the refrigerant piping line and control wiring line in the same line.
- Do not turn on the power of the indoor unit until vacuuming of the refrigerant pipes completes.

■ Wiring

1. Figure below shows the wiring connections indoor power line and between the indoor and outdoor units and between the indoor units and remote controller.
The wires indicated by the dash lines are provided at the installation place.
2. Insulate the unsheathed redundant cords (conductors) with electrical insulation tape.
Process them so that they do not touch any electrical or metal parts.

Wiring diagram



■ Power and wiring specification

Indoor fan power supply	220-240V~, 50 Hz 220V~, 60 Hz
Maximum running current	6A
Fuse rating	15A
Indoor fan power supply wire*	3 x 2.5 mm ² or more (H07RN-F or 60245 IEC 57)
System interconnection wires*	4 x 1.5 mm ² or more (H07RN-F or 60245 IEC 57)


*Number of wire x wire size

Remote controller wiring

Remote controller wiring, remote controller inter-unit wiring	Wire size: 2 × 0.5 to 2.0 mm ²	
Total wire length of remote controller wiring and remote controller inter-unit wiring = L + L1 + L2 + ... Ln	In case of wired type only	Up to 500 m
	In case of wireless type included	Up to 400 m
Total wire length of remote controller inter-unit wiring = L1 + L2 + ... Ln	Up to 200 m	

⚠ CAUTION

The remote controller wire and system interconnection wires cannot be parallel to contact each other and cannot be stored in the same conduits. If doing so, a trouble may be caused on the control system due to noise or other factor.




■ Wire connection


REQUIREMENT

- Connect the wires matching the terminal numbers. Incorrect connection causes a trouble.
- Pass the wires through the bushing of wire connection holes of the indoor unit.
- Keep a margin (Approx. 100 mm) on a wire to hang down the electrical control box at servicing or other purpose.
- The low-voltage circuit is provided for the remote controller. (Do not connect the high-voltage circuit)

- Before performing wiring work in the electrical control box, remove the cover of the box (fixed with 6 screws).
- Remove screw A, and loosen screw B.
- Pull up the electrical control box cover and then open it forward.
- Tighten the screws of the terminal block firmly, and fix the wires with the cord clamps attached to the electrical control box. (Do not apply tension to the connecting section of the terminal block.)
- Mount the cover of the electrical control box without pinching wires (fixed with 6 screws).
- Using the attached seal material, seal the wire connecting port.




Side D (Space: 8.5 mm) Side C (Space: 4 mm)



Select side C or D for the power cable clamping position referring to the following table according to the cable type and diameter.
* Cable clamp can be attached on either right or left side.
When twin system are connected, clamp two cables with one cable clamp.



Wire type	Specification	Cable clamping position
Cabletyre cable	3-core stranded wire 2.5 mm ²	Side D
Cabletyre cable	4-core stranded wire 1.5 mm ²	Side C





■ Remote controller wiring

- Strip off approx. 9 mm the wire to be connected.
- Non polarity, 2 core wire is used for wiring of the remote controller. (0.5 mm² to 2.0 mm² wires)

Wiring diagram




Group control



9 Applicable controls


REQUIREMENT

- When you use this air conditioner for the first time, it takes approx. 5 minutes until the remote controller becomes available after power-on. This is normal. **<When power is turned on for the first time after installation>** It takes approx. 5 minutes until the remote controller becomes available.



<When power is turned on for the second (or later) time>

It takes approx. 1 minute until the remote controller becomes available




- Normal settings were made when the indoor unit was shipped from factory. Change the indoor unit settings as required.
- Use the wired remote controller to change the settings.
 - The settings cannot be changed using the wireless remote controller, sub remote controller, or remote-controller-less system (for central remote controller only). Therefore, install the wired remote controller to change the settings.

Basic procedure for changing settings

Change the settings while the air conditioner is not working. **(Stop the air conditioner before making settings.)**


CAUTION

Set only the CODE No. shown in the following table: Do NOT set any other CODE No. If a CODE No. not listed is set, it may not be possible to operate the air conditioner or other trouble with the product may result.
 * The displays appearing during the setting process differ from the ones for previous remote controllers (AMT21E, AMT31E). (There are more CODE No.)



- Push and hold **TEST** button and **"TEMP."** button simultaneously for 4 seconds or more. After a while, the display flashes as shown in the figure. Confirm that the CODE No. is [01].


- If the CODE No. is not [01], push **TEST** button to clear the display content, and repeat the procedure from the beginning. (No operation of the **TEST** Remote controller is accepted for a while after button is pushed.)
 (While air conditioners are operated under the group control, "ALL" is displayed first. When **UNIT LOUVER** is pushed, the indoor unit number displayed following "ALL" is the header unit.)



(* Display content varies with the indoor unit model.)

- Each time **UNIT LOUVER** button is pushed, indoor unit numbers in the control group change cyclically. Select the indoor unit to change settings for.

The fan of the selected unit runs and the louvers start swinging. The indoor unit for change settings can be confirmed.



- Specify CODE No. [**] with **"TEMP."** button.

- Select SET DATA [****] with **"TIME."** button.


- Push **SET** button. When the display changes from flashing to lit, the setup is completed.

- To change settings of another indoor unit, repeat from Procedure 2.
- To change other settings of the selected indoor unit, repeat from Procedure 3.

Use **CL** button to clear the settings. To make settings after **CL** button was pushed, repeat from Procedure 2.

- When settings have been completed, push **TEST** button to determine the settings. When **TEST** button is pushed, **SETTING** flashes and then the display content disappears and the air conditioner enters the normal stop mode.

(While **SETTING** is flashing, no operation of the remote controller is accepted.)



External static pressure settings

Set up a tap change based upon the external static pressure of the duct to be connected.

To set up a tap change, follow to the basic operation

procedure (1 → 2 → 3 → 4 → 5 → 6).

- Specify [5d] to the CODE No. in procedure 3.
- For the SET DATA of procedure 4, select a SET DATA of the external static pressure to be set up from the following table.

<Change on wired remote controller>


SET DATA	External static pressure	
0000	50 Pa	Factory default
0001	150 Pa	—
0002	80 Pa	—
0003	200 Pa	—
0004	120 Pa	—
0005	180 Pa	—
0006	250 Pa	—

The list above is when SW501-1 and SW501-2 is OFF.

Remote controller-less setting

To set up the external static pressure, use the DIP switch on the circuit board of the wireless reception part. For details, refer to the instruction manual of the wireless remote controller kit. Alternatively, use the switch on the indoor micro computer circuit board as shown in the following figure and table.

* Once switched, the settings "0001", "0003", and "0006" can be changed, but to reset to "0000", you need to set the switch to the normal (default) position and use a separately-sold wired remote controller to overwrite the data with "0000".



SW501-1	OFF	ON	OFF	ON
SW501-2	OFF	OFF	ON	ON
SET DATA	0000 (Factory default)	0001	0003	0006

To restore the factory defaults
To return the DIP switch settings to the factory defaults, set SW501-1 and SW501-2 to OFF, connect a separately sold wired remote controller, and then set the data of CODE No. [5d] to "0000".

Filter sign setting

According to the installation condition, the filter sign term (Notification of filter cleaning) can be changed. Follow to the basic operation procedure (1 → 2 → 3 → 4 → 5 → 6).

- For the CODE No. in Procedure 3, specify [01].
- For the [SET DATA] in Procedure 4, select the SET DATA of filter sign term from the following table.

SET DATA	Filter sign term
0000	None
0001	150 H
0002	2500 H (Factory default)
0003	5000 H
0004	10000 H

To secure better effect of heating

When it is difficult to obtain satisfactory heating due to installation place of the indoor unit or structure of the room, the detection temperature of heating can be raised. Also use a circulator or other device to circulate heat air near the ceiling.

Follow to the basic operation procedure (1 → 2 → 3 → 4 → 5 → 6).


- For the CODE No. in Procedure 3, specify [06].
- For the SET DATA of procedure 4, select the SET DATA of shift value of detection temperature to be set up from the following table.

SET DATA	Detection temperature shift value
0000	No shift
0001	+1°C
0002	+2°C (Factory default)
0003	+3°C
0004	+4°C
0005	+5°C
0006	+6°C

Power saving mode


Performing settings of the power saving mode

* When RAV-SP***2AT / RAV-SM***3AT or older is used, the displayed setting changes, but the actual power level is always "75%".




- 1 Push **SAVE** button for at least 4 seconds or more when the air conditioner is not working. **SETTING** symbol flashes.

- 2 Push **UNIT LOUVER** (left side of the button) to select an indoor unit to be set.
 - Each time the button is pushed, UNIT No. change as follows:



The fan of the selected unit runs.


- 3 Push **TIME** buttons, to adjust the setting of power level.
 - Each push of the button changes the power level by 1% within the range from 100% to 50%.
 - The factory default is 75%



- 4 Push **SET** button.
- 5 Push **TEST** button to complete the setting.

Remote controller switch monitoring function

This function is available to call the service monitor mode from the remote controller even during a test run to acquire temperatures of sensors of the remote controller, indoor unit, and outdoor unit.



- 1 Push **CL** and **TEST** buttons simultaneously for at least 4 seconds to call the service monitor mode. The service monitor indicator lights up and the header indoor unit number is displayed first. CODE No. **00** is also displayed.
- 2 Pushing **TEMP** buttons, select the number of sensor, etc. (CODE No.) to be monitored. (See the following table.)
- 3 Pushing **UNIT LOUVER** (left side of the button), select an indoor unit to be monitored. The sensor temperatures of indoor units and their outdoor unit in the control group are displayed.

- 4 Push **TEST** button to return to the normal display.

Indoor unit data	
CODE No.	Data name
01	Room temperature (remote controller)
02	Indoor unit intake air temperature (TA)
03	Indoor unit heat exchanger (coil) temperature (TCJ)
04	Indoor unit heat exchanger (coil) temperature (TC)
F3	Filter sign time


Outdoor unit data	
CODE No.	Data name
60	Outdoor unit heat exchanger (coil) temperature (TE)
61	Outside air temperature (TO)
62	Compressor discharge temperature (TD)
63	Compressor suction temperature (TS)
64	—
65	Heatsink temperature (THS)
6A	Operating current (x1/10)
F1	Compressor cumulative operating hours (x100 h)

Group control

Group control for system of multiple units

One remote controller can control maximum 8 indoor units as a group.

Group control in single system



- For wiring procedure and wiring method of the individual line (Identical refrigerant line) system, follow to "Electrical connection".
- Wiring between lines is performed in the following procedure. Connect the terminal block (A/B) of the indoor unit connected with a remote controller to the terminal blocks (A/B) of the indoor units of other indoor units by wiring the inter-unit wire of the remote controller.
- When the power supply has been turned on, the automatic address setup starts and which indicates that address is being set up flashes on the display part in about 3 minutes. During setup of automatic address, the remote controller operation is not accepted.

Required time up to the finish of automatic addressing is approx. 5 minutes.


NOTE

In some cases, it is necessary to change the address manually after setup of the automatic address according to the system configuration of the group control.


[Procedure example]

Manual address setup procedure

While the operation stops, change the setup.
(Stop the operation of the unit.)



- 1** Push **SET** + **CL** + **TEST** buttons simultaneously for 4 seconds or more. After a while, the display part flashes as shown below. Check the displayed CODE No. is [10]. When the CODE No. is other than [10], push **TEST** button to clear the display and repeat procedure from the first step.
(After pushing **TEST** button, operation of the remote controller is not accepted for approx. 1 minute.)
(For a group control, No. of the firstly displayed indoor unit becomes the header unit.)




(* Display changes according to the model No. of indoor unit.)

- 2** Every time **UNIT LOUVER** button is pushed, the indoor UNIT No. in the group control is displayed in order. Select the indoor unit of which setup is changed.
In this time, the position of the indoor unit of which setup is changed can be confirmed because fan of the selected indoor unit operate.

3

- Specify CODE No. [12] with TEMP. \downarrow / \uparrow buttons.
(CODE No. [12]: Line address)
- Change the line address from [3] to [2] with TIME \downarrow / \uparrow buttons.
- Push **SET** button.
In this time, the setup finishes when the display changes from flashing to lighting.


Indoor UNIT No. before setup change is displayed.



4

- Specify CODE No. [13] with TEMP. \downarrow / \uparrow buttons.
(CODE No. [13]: Indoor address)
- Change the indoor address from [3] to [2] with TIME \downarrow / \uparrow buttons.
- Push **SET** button.
In this time, the setup finishes when the display changes from flashing to lighting.


Indoor UNIT No. before setup change is displayed.



5

- Specify CODE No. [14] with TEMP. \downarrow / \uparrow buttons.
(CODE No. [14]: Group address)
- Change the SET DATA from [0001] to [0002] TIME \downarrow / \uparrow buttons.
(SET DATA [Header unit: 0001]
[Follower unit: 0002])
- Push **SET** button.
In this time, the setup finishes when the display changes from flashing to lighting.

Indoor UNIT No. before setup change is displayed.




6

- If there is other indoor unit to be changed, repeat procedure 2 to 5 to change the setup.
When the above setup has finished, push **UNIT LOUVER** to select the indoor UNIT No. before change of setup, specify CODE No. [12], [13], [14] in order with TEMP. \downarrow / \uparrow buttons, and then check the changed contents.

Address change check Before change: [3-3-1] → After change: [2-2-2]

Pushing **CL** button clears the contents of which setup was changed.
(In this case, procedure from 2 is repeated.)


Indoor UNIT No. before setup change is displayed.



7


After check of the changed contents, push **TEST** button. (Setup is determined.) When **TEST** button is pushed, the display disappears and the status becomes the normal stopped state. (When **TEST** button is pushed the operation from the remote controller is not accepted for approx. 1 minute.)

- If the operation from the remote controller is not accepted even 1 minute or more passed after pushing **TEST** button, it is considered that the address setup is incorrect. In this case, the automatic address must be again set up. Therefore repeat procedure of the setup change from the Procedure 1.



To recognize the position of the corresponding indoor unit though the indoor UNIT No. is known

Check the position during operation stop.
(Stop operation of the unit.)




1 Push **TEST** + **VENT** buttons simultaneously for 4 seconds or more.

After a while, the display part flashes and the display appears as shown below.

In this time, the position can be checked because fan of the indoor unit operate.

- For the group control, the indoor UNIT No. is displayed as [ALL] and fans of all the indoor units in the group control operate. Check the displayed CODE No. is [01].
- When the CODE No. is other than [01], push **TEST** button to clear the display and repeat procedure from the first step. (After pushing **TEST** button, operation of the remote controller is not accepted for approx. 1 minute.)



(* Display changes according to the model No. of indoor unit.)

2 In the group control, every time **UNIT LOUVER** button is pushed, the indoor UNIT No. in the group control is displayed in order.


In this time, the position of the indoor unit can be confirmed because only fan of the selected indoor unit operate.

(For a group control, No. of the firstly displayed indoor unit becomes the header unit.)

3 After confirmation, push **TEST** button to return to the normal mode.

When **TEST** button is pushed, the display disappears and the status becomes the normal stopped state.

(When **TEST** button is pushed the operation from the remote controller is not accepted for approx. 1 minute.)




■ 8°C Operation

Pre-heating operation can be set for cold regions where room temperature drops to below zero.

1 Push **SET** + **CL** + **TEST** buttons simultaneously for 4 seconds or more when the air conditioner is not working.

After a while, the display part flashes as shown below. Check the Displayed CODE No. is [10].

- When the CODE No. is other than [10], push **TEST** button to erase the display and repeat procedure from the first step. (After pushing **TEST** button, operation of the remote controller is not accepted for approx. 1 minute.)



(* Display changes according to the model No. of indoor unit.)

2 Every time **UNIT LOUVER** button is pushed, the indoor unit No. in the group control is displayed in order. Select the indoor unit of which setup is changed. In this time, the position of the indoor unit of which setup is changed can be confirmed because fan of the selected indoor unit operate.

3 Specify CODE No. [d1] TEMP. **DOWN** / **UP** buttons.

4 Select SET DATA [0001] TIME **DOWN** / **UP** buttons.

SET DATA	8°C Operation setting
0000	None (Factory default)
0001	8°C Operation setting

5 Push **SET** button.
In this time, the setup finishes when the display changes from flashing to lighting.

6 Push **TEST** button.(Setup is determined.)
When **TEST** button is pushed, the display disappears and the status becomes the usual stop status. (When **TEST** button is pushed the operation from the remote controller is not accepted for approx. 1 minute.)

10 Test run

Before test run

- Before turning on the power supply, carry out the following procedure.
 - By using 500V-megger, check that resistance of 1MΩ or more exists between the terminal block 1 to 3 and the earth (grounding). If resistance of less than 1MΩ is detected, do not run the unit.
 - Check the valve of the outdoor unit being opened fully.
- To protect the compressor at activation time, leave power-ON for 12 hours or more before operating.


Execute a test run

Operate the unit with the wired remote controller as usual.
 For the procedure of the operation, refer to the attached Owner's Manual.
 A forced test run can be executed in the following procedure even if the operation stops by thermostat-OFF.
 In order to prevent a serial operation, the forced test run is released after 60 minutes have passed and returns to the usual operation.


CAUTION

Do not use the forced test run for cases other than the test run because it applies an excessive load to the devices.


Wired remote controller




- Push **TEST** button for 4 seconds or more. [TEST] is displayed on the display part and the selection of mode in the test mode is permitted.



- Push **ON/OFF** button.
- Select the operation mode with **MODE** button.
 - Do not run the air conditioner in a mode other than [Cool] or [Heat].
 - The temperature controlling function does not work during test run.
 - The detection of error is performed as usual.



- After the test run, push **ON/OFF** button to stop a test run. (Display part is same as procedure 1.)
- Push **TEST** button to cancel (release from) the test run mode. ([TEST] disappears on the display and the status returns to a normal.)




11 Maintenance

<Daily maintenance>

▼ Cleaning of air filter (Sold separately: TCB-LK1401D-E)
 If  is displayed on the remote controller, maintain the air filter.

- Push the **ON/OFF** button to stop the operation, then turn off the circuit breaker. After the cooling or dry operation, the fan keeps running for self-cleaning. Push the **ON/OFF** button twice to stop the operation.



- Take out the air filter. (Sold separately)
- Cleaning with water or vacuum cleaner
 - If dirt is heavy, clean the air filter by tepid water with neutral detergent or water.
 - After cleaning with water, dry the air filter sufficiently in a shade place.
- Mount the air filter. (Sold separately)

- Turn on the circuit breaker, then push the **ON/OFF** button on the remote controller to start the operation.
- After cleaning, push **FILTER RESET**.  display disappears.

CAUTION

- Do not start the air conditioner while leaving air filter removed.
- Push the filter reset button. ( indication will be turn off.)

▼ Periodic Maintenance

For environmental conservation, it is strongly recommended that the indoor and outdoor units of the air conditioner in use be cleaned and maintained regularly to ensure efficient operation of the air conditioner.

When the air conditioner is operated for a long time, periodic maintenance (once a year) is recommended. Furthermore, regularly check the outdoor unit for rust and scratches, and remove them or apply rustproof treatment, if necessary.

As a general rule, when an indoor unit is operated for 8 hours or more daily, clean the indoor unit and outdoor unit at least once every 3 months. Ask a professional for this cleaning / maintenance work.

Such maintenance can extend the life of the product though it involves the owner's expense.


Failure to clean the indoor and outdoor units regularly will result in poor performance, freezing, water leakage, and even compressor failure.

Inspection before maintenance (Once a year)

Following inspection must be carried out by a qualified installer or qualified service person.

Parts	Inspection method
Fan motor	Access from the access panel and check if any abnormal noise can be heard.
Fan	Access from the access panel and remove the access panel. Examine the fan if there are any waggles, damages or adhesive dust.
Filter (sold separately)	Access from check port and check if there are any stains or breaks on the filter.
Drain pan	Access from the access panel and remove the access panel. Check if there is any clogging or drain water is polluted.

- The unit can be accessed from the access panel shown in the figure.



▼ Maintenance List


Parts	Unit	Check (visual / auditory)	Maintenance
Heat exchanger	Indoor / outdoor	Dust / dirt clogging, scratches	Wash the heat exchanger when it is clogged.
Fan motor	Indoor / outdoor	Sound	Take appropriate measures when abnormal sound is generated.
Filter	Indoor	Dust / dirt, breakage	<ul style="list-style-type: none"> • Wash the filter with water when it is contaminated. • Replace it when it is damaged.
Fan	Indoor	<ul style="list-style-type: none"> • Vibration, balance • Dust / dirt, appearance 	<ul style="list-style-type: none"> • Replace the fan when vibration or balance is terrible. • Brush or wash the fan when it is contaminated.
Air intake / discharge grilles	Indoor / outdoor	Dust / dirt, scratches	Fix or replace them when they are deformed or damaged.
Drain pan	Indoor	Dust / dirt clogging, drain contamination	Clean the drain pan and check the downward slope for smooth drainage.
Ornamental panel, louveres	Indoor	Dust / dirt, scratches	Wash them when they are contaminated or apply repair coating.
Exterior	Outdoor	<ul style="list-style-type: none"> • Rust, peeling of insulator • Peeling / lift of coat 	Apply repair coating.

12 Troubleshooting

■ Confirmation and check

When an error occurred in the air conditioner, an error code and indoor UNIT No. appear on the display part of the remote controller.


The error code is only displayed during the operation. If the display disappears, operate the air conditioner according to the following "Confirmation of error log" for confirmation.



■ Confirmation of error log

When an error occurred on the air conditioner, the error log can be confirmed with the following procedure.


(The error log is stored in memory up to 4 errors.)
The log can be confirmed from both operating status and stop status.



- 1 When **SET** and **TEST** buttons are pushed simultaneously for 4 seconds or more, the following display appears.

If **⚠** is displayed, the mode enters in the error log mode.

- [01: Order of error log] is displayed in CODE No.
- [Error code] is displayed in CHECK.
- [Indoor unit address in which an error occurred] is displayed in UNIT No.



- 2 Every pushing of **TEMP.** button used to set temperature, the error log stored in memory is displayed in order.

The numbers in CODE No. indicate CODE No. [01] (latest) → [04] (oldest).

REQUIREMENT

Do not push **CL** button because all the error log of the indoor unit will be deleted.

- 3 After confirmation, push **TEST** button to return to the usual display.

■ Error codes and parts to be checked

Wired remote controller display	Wireless remote controller Sensor block display of receiving unit		Main defective parts	Judging device	Parts to be checked / error description	Air conditioner status
	Operation Timer Ready GR GR OR	Flashing				
Indication	Operation Timer Ready GR GR OR	Flashing				
E01	⊙ ● ●		No header remote controller Remote controller communication error	Remote controller	Incorrect remote controller setting --- The header remote controller has not been set (including two remote controllers). No signal can be received from the indoor unit.	*
E02	⊙ ● ●		Remote controller transmission error	Remote controller	System interconnection wires, indoor P.C. board, remote controller --- No signal can be sent to the indoor unit.	*
E03	⊙ ● ●		Indoor unit-remote controller regular communication error	Indoor	Remote controller, network adapter, indoor P.C. board --- No data is received from the remote controller or network adapter.	Auto-reset
E04	● ● ⊙		Indoor unit-outdoor unit serial communication error IPDU-CDB communication error	Indoor	System interconnection wires, indoor P.C. board, outdoor P.C. board --- Serial communication error between indoor unit and outdoor unit	Auto-reset
E08	⊙ ● ●		Duplicated indoor addresses ★	Indoor	Indoor address setting error --- The same address as the self-address was detected.	Auto-reset
E09	⊙ ● ●		Duplicated header remote controllers	Remote controller	Remote controller address setting error --- Two remote controllers are set as header in the doubleremote controller control. (* The header indoor unit stops raising alarm and follower indoor units continue to operate.)	*
E10	⊙ ● ●		CPU-CPU communication error	Indoor	Indoor P.C. board --- Communication error between main MCU and motor microcomputer MCU	Auto-reset
E18	⊙ ● ●		Header unit follower unit regular communication error	Indoor	Indoor P.C. board --- Regular communication is not possible between header and follower indoor units or between twin header (main) and follower (sub) units.	Auto-reset
E31	● ● ⊙		IPDU communication error	Outdoor	Communication error between IPDU and CDB	Entire stop
F01	⊙ ⊙ ●	ALT	Indoor unit heat exchanger sensor (TCJ) error	Indoor	Heat exchanger sensor (TCJ), indoor P.C. board --- Open-circuit or short-circuit of the heat exchanger sensor (TCJ) was detected.	Auto-reset
F02	⊙ ⊙ ●	ALT	Indoor unit heat exchanger sensor (TCJ) error	Indoor	Heat exchanger sensor (TC), indoor P.C. board --- Open-circuit or short-circuit of the heat exchanger sensor (TC) was detected.	Auto-reset
F04	⊙ ⊙ ○	ALT	Outdoor unit discharge temp. sensor (TD) error	Outdoor	Outdoor temp. sensor (TD), outdoor P.C. board --- Open-circuit or short-circuit of the discharge temp. sensor was detected.	Entire stop
F06	⊙ ⊙ ○	ALT	Outdoor unit temp. sensor (TE / TS) error	Outdoor	Outdoor temp. sensors (TE / TS), outdoor P.C. board --- Open-circuit or short-circuit of the heat exchanger temp. sensor was detected.	Entire stop
F07	⊙ ⊙ ○	ALT	TL sensor error	Outdoor	TL sensor may be displaced, disconnected or short-circuited.	Entire stop
F08	⊙ ⊙ ○	ALT	Outdoor unit outside air temp. sensor error	Outdoor	Outdoor temp. sensor (TO), outdoor P.C. board --- Open-circuit or short-circuit of the outdoor air temp. sensor was detected.	Operation continued
F10	⊙ ⊙ ●	ALT	Indoor unit room temp. sensor (TA) error	Indoor	Room temp. sensor (TA), indoor P.C. board --- Open-circuit or short-circuit of the room temp. sensor (TA) was detected.	Auto-reset
F12	⊙ ⊙ ○	ALT	TS sensor error	Outdoor	TS sensor may be displaced, disconnected or short-circuited.	Entire stop
F13	⊙ ⊙ ○	ALT	Heat sink sensor error	Outdoor	Abnormal temperature was detected by the temp. sensor of the IGBT heat sink.	Entire stop
F15	⊙ ⊙ ○	ALT	Temp. sensor connection error	Outdoor	Temp. sensor (TE / TS) may be connected incorrectly	Entire stop
F29	⊙ ⊙ ●	SIM	Indoor unit, other P.C. board error	Indoor	Indoor P.C. board --- EEPROM error	Auto-reset

Wired Remote controller display	Wireless remote controller Sensor block display of receiving unit		Main defective parts	Judging device	Parts to be checked / error description	Air conditioner status
	Indication	Operation Timer Ready GR GR OR				
F31	⊙ ⊙ ○		Outdoor unit P.C. board	Outdoor	Outdoor P.C. board --- In the case of EEPROM error.	Entire stop
H01	● ⊙ ●		Outdoor unit compressor breakdown	Outdoor	Current detect circuit, power voltage --- Minimum frequency was reached in the current releasing control or short-circuit current (Idc) after direct excitation was detected	Entire stop
H02	● ⊙ ●		Outdoor unit compressor lock	Outdoor	Compressor circuit --- Compressor lock was detected.	Entire stop
H03	● ⊙ ●		Outdoor unit current detect circuit error	Outdoor	Current detect circuit, outdoor unit P.C. board --- Abnormal current was detected in AC-CT or a phase loss was detected.	Entire stop
H04	● ⊙ ●		Case thermostat operation	Outdoor	Malfunction of the case thermostat	Entire stop
H06	● ⊙ ●		Outdoor unit low-pressure system error	Outdoor	Current, high-pressure switch circuit, outdoor P.C. board --- Pressure sensor error was detected or low-pressure protective operation was activated.	Entire stop
L03	⊙ ● ⊙	SIM	Duplicated header indoor units ★	Indoor	Indoor address setting error --- There are two or more header units in the group.	Entire stop
L07	⊙ ● ⊙	SIM	Group line in individual indoor unit ★	Indoor	Indoor address setting error --- There is at least one group-connected indoor unit among individual indoor units.	Entire stop
L08	⊙ ● ⊙	SIM	Indoor group address not set ★	Indoor	Indoor address setting error --- Indoor address group has not been set.	Entire stop
L09	⊙ ● ⊙	SIM	Indoor unit capacity not set	Indoor	Indoor unit capacity has not been set.	Entire stop
L10	⊙ ○ ⊙	SIM	Outdoor unit P.C. board	Outdoor	In the case of outdoor P.C. board jumper wire (for service) setting error	Entire stop
L20	⊙ ○ ⊙	SIM	LAN communication error	Network adapter central control	Address setting, central control remote controller, network adapter --- Duplication of address in central control communication	Auto-reset
L29	⊙ ○ ⊙	SIM	Other outdoor unit error	Outdoor	Other outdoor unit error	Entire stop
					1) Communication error between IPDU MCU and CDB MCU 2) Abnormal temperature was detected by the heat sink temp. sensor in IGBT.	Entire stop
L30	⊙ ○ ⊙	SIM	Abnormal external input into indoor unit (interlock)	Indoor	External devices, outdoor unit P.C. board --- Abnormal stop due to incorrect external input into CN80	Entire stop
L31	⊙ ○ ⊙	SIM	Phase sequence error, etc.	Outdoor	Power supply phase sequence, outdoor unit P.C. board --- Abnormal phase sequence of the 3-phase power supply	Operation continued (thermost at OFF)
P01	● ⊙ ⊙	ALT	Indoor unit fan error	Indoor	Indoor fan motor, indoor P.C. board --- Indoor AC fan error (fan motor thermal relay activated) was detected.	Entire stop
P03	⊙ ● ⊙	ALT	Outdoor unit discharge temp. error	Outdoor	An error was detected in the discharge temp. releasing control.	Entire stop
P04	⊙ ● ⊙	ALT	Outdoor unit high-pressure system error	Outdoor	High-pressure switch --- The IOL was activated or an error was detected in the high-pressure releasing control using the TE.	Entire stop
P05	⊙ ● ⊙	ALT	Open phase detected	Outdoor	The power wire may be connected incorrectly. Check open phase and voltages of the power supply.	Entire stop
P07	⊙ ● ⊙	ALT	Heat sink overheat	Outdoor	Abnormal temperature was detected by the temp. sensor of the IGBT heat sink.	Entire stop
P10	● ⊙ ⊙	ALT	Indoor unit water overflow detected	Indoor	Drain pipe, clogging of drainage, float switch circuit, indoor P.C. board --- Drainage is out of order or the float switch was activated.	Entire stop

Wired remote controller display	Wireless remote controller Sensor block display of receiving unit		Main defective parts	Judging device	Parts to be checked / error description	Air conditioner status
	Indication	Operation Timer Ready GR GR OR				
P12	● ○ ○	ALT	The fan error of the indoor unit	Indoor	Abnormal operation of the indoor fan motor, indoor P.C. board, or indoor DC fan (over current or lock, etc.) is detected. External static pressure setting error.	Entire stop
P15	○ ● ○	ALT	Gas leakage detected	Outdoor	There may be gas leakage from the pipe or connecting part. Check for gas leakage.	Entire stop
P19	○ ● ○	ALT	4-way valve error	Outdoor (Indoor)	4-way valve, indoor temp. sensors (TC / TCJ) --- An error was detected due to temperature drop of the indoor unit heat exchanger sensor when heating.	Auto-reset
P20	○ ● ○	ALT	High-pressure protective operation	Outdoor	High-pressure protection	Entire stop
P22	○ ● ○	ALT	Outdoor unit fan error	Outdoor	Outdoor unit fan motor, outdoor unit P.C. board --- An error (overcurrent, locking, etc.) was detected in the outdoor unit fan drive circuit.	Entire stop
P26	○ ● ○	ALT	Outdoor unit inverter Idc activated	Outdoor	IGBT, outdoor unit P.C. board, inverter wiring, compressor --- Short-circuit protection for compressor drive circuit devices (G-Tr / IGBT) was activated.	Entire stop
P29	○ ● ○	ALT	Outdoor unit position error	Outdoor	Outdoor unit P.C. board, high-pressure switch --- Compressor motor position error was detected.	Entire stop
P31	○ ● ○	ALT	Other indoor unit error	Indoor	Another indoor unit in the group is raising an alarm.	Entire stop
					E03 / L07 / L03 / L08 alarm check locations and error description	Auto-reset

○ : Lighting ○ : Flashing ● : OFF ★ : The air conditioner automatically enters the auto-address setting mode.
 ALT: When two LEDs are flashing, they flash alternately. SIM: When two LEDs are flashing, they flash in synchronization.
 Receiving unit display OR: Orange GR: Green

حالة مكيف هواء	الأجزاء التي سيتم فحصها / وصف الخطأ	جهاز التحكم	الأجزاء المعيبة الرئيسية	جهاز التحكم عن بُعد اللاسلكي			شاشنة عرض مجموعة المستشعرات بوحدة الاستقبال	شاشنة جهاز التحكم عن بُعد السلعي
				وميض	التنديل مؤقت حذر OR GR GR	التوضيح		
إيقاف كامل	قد يكون هناك تسريب غاز من الأنابيب أو جزء التوصيل. الفحص عن تسريب غاز.	الوحدة الخارجية	اكتشاف تسريب غاز	ALT	●	○	P15	
إعادة الضبط التلقائي (إعادة الضبط التلقائي)	صمام رداي الاتمام مستشعرات درجات حرارة الوحدة الداخلية (TC / TCJ) --- تم اكتشاف خطأ نظرا لانخفاض درجة حرارة مستشعر حرارة الوحدة الداخلية عند التذفة.	الوحدة الخارجية (الوحدة الداخلية)	خطأ في الصمام رداي الاتمام	ALT	●	○	P19	
إيقاف كامل	حماية الضغط العالي	الوحدة الخارجية	التشغيل الوقائي عالي الضغط	ALT	●	○	P20	
إيقاف كامل	محرك مروحة الوحدة الخارجية لوحدة الدائرة المطبوعة للوحدة الخارجية --- تم اكتشاف خطأ (تيار مغلف، قفل، وما إلى ذلك) في دائرة محرك مروحة الوحدة الخارجية.	الوحدة الخارجية	خطأ في مروحة الوحدة الخارجية	ALT	●	○	P22	
إيقاف كامل	IGBT لوحدة الدائرة المطبوعة للوحدة الخارجية، شبكة أسلاك المحول، الضاغطة --- تم تنشيط حماية الدائرة القصور لأجهزة دائرة محرك الضاغطة (G-Tr / IGBT) مجلس في.	الوحدة الخارجية	تنشيط محول التيار غير المباشر للوحدة الخارجية	ALT	●	○	P26	
إيقاف كامل	لوحة الدائرة المطبوعة للوحدة الخارجية مفتاح الضغط العالي --- تم اكتشاف خطأ في موضع محرك الضاغطة.	الوحدة الخارجية	خطأ في موضع الوحدة الخارجية	ALT	●	○	P29	
إيقاف كامل	تصدر وحدة داخلية أخرى في المجموعة إنذار.	الوحدة الداخلية	خطأ في وحدة داخلية أخرى	ALT	●	○	P31	
إعادة الضبط التلقائي	مواقع فحص الإنذار E03 / L07 / L03 / L08 وتوصيف الخطأ							

○ : ضوء ● : إيقاف ★ : يدخل مكيف الهواء تلقائيا وضع ضبط العنوان التلقائي.
 ALT : عندما تومض لمبةي حتى الـ LEDs، فإنهما يومضان بالتناوب. SIM : عندما تومض لمبةي حتى الـ LEDs، فإنهما يومضان بالتزامن.
 شاشنة عرض وحدة الاستقبال OR: برتقالي GR : خضراء

■ رموز الفحص والأجزاء التي يتم فحصها

حالة مكيف هواء	الأجزاء التي سيتم فحصها / وصف الخطأ	جهاز التحكم	جهاز التحكم عن بُعد اللاسلكي			التوضيح	شاشية جهاز التحكم عن بُعد	جهاز التحكم عن بُعد اللاسلكي			
			شاشية عرض مجموعة المستشعرات بوحدة الاستقبال					التعديل مؤقت حاد	OR	GR	GR
			وميض	وميض	وميض						
حالة مكيف هواء	الأجزاء التي سيتم فحصها / وصف الخطأ	جهاز التحكم	التوضيح	شاشية جهاز التحكم عن بُعد	جهاز التحكم عن بُعد اللاسلكي	شاشية عرض مجموعة المستشعرات بوحدة الاستقبال	وميض	وميض	وميض		
*	إعداد غير صحيح لجهاز التحكم عن بُعد --- لم يتم ضبط مشعب جهاز التحكم عن بُعد (بما في ذلك جهازي التحكم عن بُعد). لا يمكن استقبال إشارة من الوحدة الداخلية	جهاز التحكم عن بُعد	لا يوجد مشعب جهاز تحكم عن بُعد خطأ في اتصال جهاز التحكم عن بُعد	● ● ●	● ● ●	● ● ●					
*	أسلاك الربط البيئي للنظام. وحدة الدائرة المطبوعة للوحدة الداخلية، جهاز التحكم عن بُعد --- لا يمكن إرسال إشارة إلى الوحدة الداخلية.	جهاز التحكم عن بُعد	خطأ في بث جهاز التحكم عن بُعد	● ● ●	● ● ●	● ● ●					
إعادة الضبط	خطأ في الاتصال المنظم لجهاز التحكم عن بُعد للوحدة الداخلية	الوحدة الداخلية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إعادة الضبط	خطأ في الاتصال المشتمل للوحدة الداخلية - الوحدة الخارجية	الوحدة الداخلية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إعادة الضبط	خطأ في الاتصال المشتمل للوحدة الداخلية --- خطأ في الاتصال المشتمل بين الوحدة الداخلية والوحدة الخارجية	الوحدة الداخلية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إعادة الضبط	خطأ في إعداد عنوان الوحدة الداخلية --- تم اكتشاف نفس العنوان كالعنوان الذاتي.	الوحدة الداخلية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
*	خطأ في إعداد عنوان الوحدة الداخلية --- تم ضبط جهازي تحكم عن بُعد كمشعب في جهاز التحكم في أجهزة التحكم عن بُعد المرادجة (* يتوقف مشعب الوحدة الداخلية مسدداً إنذاراً وتستمر الوحدات الداخلية التابعة في العمل).	جهاز التحكم عن بُعد	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إعادة الضبط	وحدة الدائرة المطبوعة للوحدة الداخلية --- خطأ في الاتصال بين وحدة MCU الرئيسية ووحدة MCU للكمبيوتر الدقيق للمحرك	الوحدة الداخلية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إعادة الضبط	خطأ في الاتصال المشتمل للوحدة الداخلية --- الاتصال المنظم غير ممكن بين المشعب والوحدات الداخلية التابعة	الوحدة الداخلية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إيقاف كامل	خطأ في الاتصال بين IPDU و CDB	الوحدة الخارجية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إعادة الضبط	مستشعر المبادل الحراري (TCJ). وحدة الدائرة المطبوعة للوحدة الداخلية --- تم اكتشاف دائرة مفتوحة أو دائرة قصيرة لمستشعر المبادل الحراري.	الوحدة الداخلية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إعادة الضبط	مستشعر درجة حرارة المبادل الحراري (TC). وحدة الدائرة المطبوعة للوحدة الداخلية --- تم اكتشاف دائرة مفتوحة أو دائرة قصيرة لمستشعر المبادل الحراري.	الوحدة الداخلية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إيقاف كامل	مستشعر درجة حرارة الوحدة الخارجية (TD). وحدة الدائرة المطبوعة للوحدة الخارجية --- تم اكتشاف دائرة مفتوحة أو دائرة قصيرة لمستشعر درجة حرارة تبريق الهواء.	الوحدة الخارجية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إيقاف كامل	مستشعر درجة حرارة الوحدة الخارجية (TE / TS). وحدة الدائرة المطبوعة للوحدة الداخلية --- تم اكتشاف دائرة مفتوحة أو دائرة قصيرة لمستشعر درجة حرارة المبادل الحراري.	الوحدة الخارجية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إيقاف كامل	خطأ في استقبال مستشعر TL. أو فصله أو يحدث له دائرة قصيرة.	الوحدة الخارجية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
استمرار التشغيل	مستشعر درجة حرارة الوحدة الخارجية (TO). وحدة الدائرة المطبوعة للوحدة الخارجية --- تم اكتشاف دائرة مفتوحة أو دائرة قصيرة لمستشعر درجة حرارة المبادل الحراري.	الوحدة الخارجية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إعادة الضبط	مستشعر درجة حرارة الغرفة (TA). وحدة الدائرة المطبوعة للوحدة الداخلية --- تم اكتشاف دائرة مفتوحة أو دائرة قصيرة لمستشعر درجة حرارة تبريق الهواء.	الوحدة الداخلية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إيقاف كامل	خطأ في استقبال مستشعر TS. أو فصله أو يحدث له دائرة قصيرة.	الوحدة الخارجية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					
إيقاف كامل	تم اكتشاف درجة حرارة غير عادية بواسطة مستشعر حرارة المثلث الحراري IGBT.	الوحدة الخارجية	خطأ في الإعداد التلقائي	● ● ●	● ● ●	● ● ●					

حالة مكيف هواء	الأجزاء التي سيتم فحصها / وصف الخطأ	جهاز التحكم	الأجزاء المعيبة الرئيسية	جهاز التحكم عن بُعد اللاسلكي			التوضيح	شاشية جهاز التحكم عن بُعد
				وميض	شاشية مؤقت حاد	وميض		
إيقاف كامل	يمكن أن يكون مستشعر الحرارة (TE / TS) موصل بطريقة غير صحيحة.	الوحدة الخارجية	خطأ في توصيل مستشعر درجة حرارة.	ALT	○ ● ●	○ ● ●	F15	
إعادة الضبط	وحدة الدائرة المطبوعة للوحدة الخارجية - خطأ --- EEPROM	الوحدة الداخلية	خطأ آخر في الوحدة الداخلية	SIM	● ● ●	○ ● ●	F29	
إيقاف كامل	وحدة الدائرة المطبوعة للوحدة الخارجية --- في حالة وجود خطأ EEPROM.	الوحدة الخارجية	خطأ آخر في الوحدة الخارجية	SIM	○ ● ●	○ ● ●	F31	
إيقاف كامل	تم الوصول إلى دائرة كشف التيار، وجهد الطاقة --- الحد الأدنى للتردد في التحكم في إطلاق التيار أو تيار الدائرة القصيرة (Idc) بعد أن تم الكشف عن الإثارة المباشرة.	الوحدة الخارجية	الوحدة الخارجية		● ● ●	○ ● ●	H01	
إيقاف كامل	دائرة الضاغطة --- تم اكتشاف إغلاق الضاغطة	الوحدة الخارجية	الوحدة الخارجية		● ● ●	○ ● ●	H02	
إيقاف كامل	دائرة كشف التيار، وحدة الدائرة المطبوعة للوحدة الداخلية --- تم اكتشاف تيار غير طبيعي في محول التيار في مكيف الهواء أو اكتشاف فقد طور.	الوحدة الخارجية	الوحدة الخارجية		● ● ●	○ ● ●	H03	
إيقاف كامل	عطل المنظم الحراري للملحة	الوحدة الخارجية	الوحدة الخارجية		● ● ●	○ ● ●	H04	
إيقاف كامل	التيار، دائرة متحاز الضغط العالي، وحدة التيار المطبوعة للوحدة الخارجية --- تم اكتشاف خطأ في مستشعر الضغط أو تم تنشيط العملية الوقائية منخفضة الضغط.	الوحدة الخارجية	خطأ في نظام الوحدة الخارجية		● ● ●	○ ● ●	H06	
إيقاف كامل	خطأ في إعداد عنوان الوحدة الداخلية --- هناك وحدتان مشعب أو أكثر في المجموعة.	الوحدة الداخلية	مشعب مزوج للوحدات الداخلية ★	SIM	○ ● ●	○ ● ●	L03	
إيقاف كامل	خطأ في إعداد عنوان الوحدة الداخلية --- هناك على الأقل وحدة داخلية واحدة مرتبطة بالمجموعة بين الوحدات الداخلية القريبة.	الوحدة الداخلية	خط المجموعة في وحدة داخلية ★	SIM	○ ● ●	○ ● ●	L07	
إيقاف كامل	خطأ في إعداد عنوان الوحدة الداخلية --- لم يتم ضبط مجموعة عناوين الوحدات الداخلية.	الوحدة الداخلية	عدم ضبط مجموعة عناوين الوحدات الداخلية ★	SIM	○ ● ●	○ ● ●	L08	
إيقاف كامل	خطأ في إعداد عنوان الوحدة الداخلية --- تم ضبط مستوى الطاقة للوحدات الداخلية.	الوحدة الداخلية	عدم ضبط مستوى الطاقة للوحدات الداخلية	SIM	○ ● ●	○ ● ●	L09	
إيقاف كامل	في حالة وجود خطأ في إعداد توزيع الأسلاك للوحدة الدائرة المطبوعة للوحدة الخارجية (التصيانة)	الوحدة الخارجية	وحدة الدائرة المطبوعة للوحدة الخارجية	SIM	○ ● ●	○ ● ●	L10	
إعادة الضبط	إعدادات العنوان، جهاز التحكم عن بُعد في التحكم المركزي، مهام الشبكة --- مضاعفة العنوان في اتصال التحكم المركزي	التحكم المركزي	خطأ في اتصال LAN	SIM	○ ● ●	○ ● ●	L20	
إيقاف كامل	خطأ في الوحدة الخارجية الأخرى	الوحدة الخارجية	خطأ في الوحدة الخارجية الأخرى	SIM	○ ● ●	○ ● ●	L29	
إيقاف كامل	خطأ في الاتصال بين IPDU MCU و CDB MCU (١) تم اكتشاف درجة حرارة غير طبيعية بواسطة مستشعر درجة حرارة المثلث الحراري في IGBT.	الوحدة الخارجية	خطأ في الوحدة الخارجية الأخرى	SIM	○ ● ●	○ ● ●	L30	
استمرار التشغيل	تسلسل طور الإدخال بالتيار الكهربائي، وحدة الدائرة المطبوعة للوحدة الخارجية --- تسلسل طور غير طبيعي للإمداد بالتيار الكهربائي ثلاثي الطور.	الوحدة الخارجية	خطأ في تسلسل الطور	SIM	○ ● ●	○ ● ●	L31	
إيقاف كامل	تم اكتشاف خطأ في محرك مروحة الوحدة الداخلية، وحدة الدائرة المطبوعة للوحدة الداخلية --- مروحة التيار المتردد للوحدة الداخلية (المرحل الحراري لمحرك المروحة نشط).	الوحدة الداخلية	خطأ في مروحة الوحدة الداخلية	ALT	○ ● ●	○ ● ●	P01	
إيقاف كامل	تم اكتشاف خطأ في درجة حرارة تبريق الهواء الذي يحرق التحكم	الوحدة الخارجية	خطأ في مستشعر درجة حرارة تبريق الهواء الخارجية	ALT	○ ● ●	○ ● ●	P03	
إيقاف كامل	مفتاح الضغط العالي تم تنشيط --- IOL أو تم اكتشاف خطأ في الضغط العالي الذي يحرق التحكم باستخدام TE.	الوحدة الخارجية	خطأ في نظام الضغط العالي للوحدة الخارجية	ALT	○ ● ●	○ ● ●	P04	
إيقاف كامل	قد يكون تم توصيل كابل الطاقة بشكل غير صحيح. تأكد من فتح الطور وجهد الإمداد بالتيار الكهربائي.	الوحدة الخارجية	اكتشاف الطور المفتوح	ALT	○ ● ●	○ ● ●	P05	
إيقاف كامل	تم اكتشاف درجة حرارة غير عادية بواسطة مستشعر حرارة المثلث الحراري IGBT.	الوحدة الخارجية	فقد حرارة المثلث الحراري	ALT	○ ● ●	○ ● ●	P07	
إيقاف كامل	أنبوب التصريف، إمداد التصريف، دائرة متحاز الطفو، وحدة الدائرة المطبوعة للوحدة الداخلية --- يكون التصريف خارج الترتيب أو تم تنشيط مفتاح الطفو.	الوحدة الداخلية	خطأ فرط تدفق في الوحدة الداخلية	ALT	○ ● ●	○ ● ●	P10	
إيقاف كامل	تم اكتشاف تشغيل غير عادي لمحرك مروحة الوحدة الداخلية، أو وحدة دائرة مطبوعة للوحدة الداخلية، أو مروحة التيار المباشر للوحدة الداخلية (تيار زائد أو قفل، وما إلى ذلك) خطأ في إعداد الضغط الثابت الخارجي	الوحدة الداخلية	خطأ المروحة في الوحدة الداخلية	ALT	○ ● ●	○ ● ●	P12	

▼ صيانة دورية


لحفاظ على البيئة، من المستحسن بقوة أن يتم تنظيف وصيانة الودعتين الداخلية والخارجية لمكيف الهواء المستخدم بانتظام لضمان التشغيل الفعال لمكيف الهواء. عندما يتم تشغيل مكيف الهواء لفترة طويلة من الزمن، من المستحسن إجراء صيانة دورية (مرة واحدة في السنة). وعلاوة على ذلك، افحص بانتظام الوحدة الخارجية لمعرفة ما إذا كان بها صدأ وخدوش، وأزله أو وضع علاج لمنع الصدأ، إذا لزم الأمر. كقاعدة عامة، عندما يتم تشغيل الوحدة الداخلية لمدة 8 ساعات أو أكثر يومياً، قم بتنظيف الوحدة الداخلية والوحدة الخارجية مرة واحدة على الأقل كل 3 أشهر. اطلب من فني متخصص إجراء هذا التنظيف / أعمال الصيانة. يمكن أن تزيد هذه الصيانة من حياة المنتج على الرغم من أنها تكون على نفقة المالك. ويؤدي عدم تنظيف الودعتين الداخلية والخارجية بانتظام إلى ضعف الأداء، والتجميد، وتسرب المياه، وحتى إغراق الضاغط.

الفحص قبل الصيانة (مرة واحدة في السنة)

يجب إجراء الفحص التالي بواسطة أخصائي تركيب مؤهل أو فني صيانة مؤهل.

الأجزاء	طريقة الفحص
محرك المروحة	قم بالوصول من لوحة الوصول وتأكد مما إذا كان يمكن سماع أي ضوضاء غير طبيعية.
المروحة	قم بالوصول من لوحة الوصول وإزالة لوحة الوصول. افحص ما إذا كان هناك أي اهتزاز في المروحة أو أضرار أو أتربة ملتصقة.
المرشح (يباع على حدة)	قم بالوصول من منفذ الفحص وتأكد مما إذا كان هناك أي بقع أو كسور في المرشح.
مجمع الصرف	قم بالوصول من لوحة الوصول وإزالة لوحة الوصول. تأكد مما إذا كان هناك أي انسداد أو تلوث في مياه التصريف.

• يمكن الوصول إلى الوحدة من لوحة الوصول كما هو موضح في الشكل.




▼ قائمة الصيانة

الجزء	الوحدة	افحص (بالنظر / سماع صوت)	الصيانة
المبادل الحراري	الوحدة الداخلية / الوحدة الخارجية	الانسداد بالأتربة / الغبار، الخدوش	اغسل المبادل الحراري عند انسداده.
محرك المروحة	الوحدة الداخلية / الوحدة الخارجية	صوت	اتخذ التدابير المناسبة عند سماع صوت غير عادي.
المرشح	الوحدة الداخلية	الأتربة / الغبار، كسر	• اغسل المرشح عند تلوثه. • قم باستبداله عند تلفه.
المروحة	الوحدة الداخلية	• اهتزاز، تذبذب • الأتربة / الغبار، المظهر	• استبدل المروحة عند وجود اهتزاز أو تذبذب. • اغسل المروحة بفرشاة أو مياه عند تلوثها.
شبكة مدخل الهواء / شبكة تفريغ الهواء	الوحدة الداخلية / الوحدة الخارجية	الأتربة / الغبار، الخدوش	قم بتثبيت أو استبدالها عندما تتشوه أو تتلف.
مجمع الصرف	الوحدة الداخلية	الانسداد بالأتربة / الغبار، تلوث التصريف	قم بتنظيف مجمع الصرف وافحص المنحدر الأسفل لسهولة التصريف.
الوحدة الزينية، شقوق التهوية	الوحدة الداخلية	الأتربة / الغبار، الخدوش	اغسلها عندما تتلوث أو أجري صيانة للطلاء.
الواجهة الخارجية	الوحدة الخارجية	• صدأ أو تقشر العازل • تقشر / رفع الطلاء	وضع طلاء الإصلاح.

١٢ التحري عن الخلل وإصلاحه

■ التأكيد والفحص

عند حدوث خطأ في مكيف الهواء، تأكد من رمز الخطأ ورقم الوحدة الداخلية على جزء الشاشة من جهاز التحكم عن بعد. لا يتم عرض رمز الفحص إلا أثناء التشغيل. إذا اختفت شاشة العرض، قم بتشغيل مكيف الهواء وفقاً «لسجل فحص الخطأ» للتأكيد.




رقم الوحدة الداخلية التي حدث بها خطأ
رمز الفحص

■ سجل تأكيد الخطأ

عند حدوث خطأ في مكيف الهواء، يمكن التأكد من سجل الأخطاء في الإجراء التالي.


(يتم تخزين سجل الأخطاء في ذاكرة بما يصل إلى 4 أخطاء). يمكن تأكيد السجل من كل من حالة التشغيل وحالة الإيقاف.



عند الضغط على الزرين **TEST** و **SET** في نفس الوقت لمدة 4 ثوانٍ أو أكثر تظهر الشاشة التالية.

إذا ظهر رمز يدخل الوضع في وضع سجل الأخطاء.

- [01]: ترتيب سجل الأخطاء [معروض في رقم الرمز.
- [رمز الخطأ] معروض في الفحص.
- [عنوان الوحدة الداخلية التي حدث بها خطأ] معروض في رقم الوحدة.



في كل مرة يتم فيها الضغط على زر **TEMP.** لضبط درجة الحرارة، يتم عرض سجل الأخطاء بالترتيب.

الأرقام في رقم الرمز توضح رقم الرمز [01] (الأخير) → [04] (الأقدم).

المتطلبات

لا تضغط على الزر **CL** لأنه سيتم حذف جميع الأخطاء في سجل أخطاء الوحدة الداخلية.


بعد التأكيد، اضغط على الزر **TEST** للعودة إلى شاشة العرض العادية.

١١ الصيانة

<الصيانة اليومية>

▼ تنظيف مرشح الهواء (يُباع على حدة: TCB-LK1401D-E)
إذا تم عرض  على جهاز التحكم عن بُعد، أجزى صيانة لمرشح الهواء.

١ اضغط المفتاح  للإيقاف ثم أوقف قاطع التيار.
بعد التشغيل الجاف أو التبريد، سوف تظل المروحة تعمل للتنظيف الذاتي.
اضغط على  زر مرتين لإيقاف التشغيل.



١. إخراج مرشح الهواء. (يُباع على حدة)
٢. التنظيف بماء ومكنسة كهربائية
- إذا كان الغبار كثيرا، نظف مرشح الهواء بمياه فاترة مع مادة منظفة محايدة أو مياه.
- بعد التنظيف بالماء، جفف مرشح الهواء بشكل كافٍ في مكان الظل.
٣. علق مرشح الهواء. (يُباع على حدة)

٢ قم بتشغيل قاطع الدائرة، ثم اضغط على زر  في جهاز التحكم عن بُعد لبدء التشغيل.

٣ بعد التنظيف، اضغط على .
تختفي شاشة .

⚠ تنبيه


- لا تقم بتشغيل مكيف الهواء أثناء إزالة مرشح الهواء.
- اضغط زر إعادة ضبط مرشح الهواء. (يقف تشغيل مؤشر ).

١٠ التشغيل التجريبي


■ قبل التشغيل التجريبي

- قبل تشغيل مصدر الإمداد بالتيار الكهربائي، قم بالإجراء التالي.
(١) باستخدام جهاز اختبار عزل قدرته ٥٠٠ فولت، تأكد من وجود مقاومة قدرها ١ ميجا أوم أو أكثر بين مجموعة النهايات الطرفية ١ إلى ٣ والأرضي (التأريض).
إذا كانت المقاومة أقل من ١ ميجا أوم لا تقم بتشغيل الوحدة.
(٢) تأكد من أن صمام الوحدة الخارجية مفتوح تماما.
- لحماية الضاغط في وقت التشغيل، اترك مفتاح التيار مفتوحا لمدة ١٢ ساعة أو أكثر قبل التشغيل.

جهاز التحكم عن بُعد السلكي




١ اضغط زر  لمدة ٤ ثوانٍ أو أكثر.
تظهر كلمة [اختبار] على الجزء الخاص بالعرض ويسمح باختيار الوضع من وضع الاختبار.



٢ اضغط زر .

٣ اختر وضع التشغيل بالضغط على زر , [Cool❄️] (تبريد) أو [Heat❄️] (تدفئة).


- يحظر تشغيل مكيف الهواء في وضع غير [Cool❄️] (تبريد) أو [Heat❄️] (تدفئة).
- وظيفة التحكم في درجة الحرارة لا تعمل أثناء التشغيل التجريبي.
- يرجى اكتشاف الخطأ كالعادة.



٤ بعد التشغيل التجريبي، اضغط على زر  لإيقاف التشغيل التجريبي.


(يكون جزء عرض الشاشة نفس الإجراء ١)

٥ اضغط زر  لإلغاء (للتحرر من) وضع التشغيل التجريبي.
(تختفي كلمة [TEST] تجريبية على الشاشة، وتعود الحالة إلى طبيعي.)



للمعرفة موقع الوحدة الداخلية المقابلة رغم معرفة رقم الوحدة الداخلية معروفة

افحص الموقع أثناء إيقاف التشغيل.
(أوقف تشغيل الجهاز.)




3 ضغط زر $\text{TEST} + \text{VENT}$ مع لمدة 4 ثوانٍ أو أكثر.
بعد فترة وجيزة، يومض جزء الشاشة، وتظهر الشاشة على النحو الموضح أدناه.
في هذا الوقت، يمكن فحص الموقع لأن المروحة للوحدة الداخلية تكون قيد التشغيل.

- بالنسبة لمجموعة التحكم، يتم عرض رقم الوحدة الداخلية حيث تكون [ALL] المراوح لجميع الوحدات الداخلية في مجموعة التحكم قيد التشغيل. تأكد من أن رقم الرمز هو [01].
- إذا كان رقم الرمز ليس [01]، اضغط زر TEST لمسح محتوى الشاشة، وكرر الإجراء من الخطوة الأولى. (بعد الضغط على زر TEST ، لن يقبل تشغيل جهاز التحكم عن بُعد لمدة دقيقة تقريباً.)



2 في مجموعة التحكم، في كل مرة تضغط على زر UNIT LOUVER ، يتم عرض رقم الوحدة الداخلية في مجموعة التحكم بالترتيب. في هذا الوقت، يمكن فحص موقع الوحدة الداخلية لأن المروحة للوحدة الداخلية المختارة تكون قيد التشغيل. (لمجموعة تحكم، يصبح رقم الوحدة الداخلية المعروض أولاً هو وحدة المشعب.)


3 بعد التأكيد، اضغط على زر TEST للعودة إلى الوضع العادي. عند الضغط على زر TEST ، تختفي الشاشة وتصبح الحالة حالة إيقاف عادي. (عند الضغط على زر TEST ، لن يقبل تشغيل جهاز التحكم عن بُعد لمدة 1 دقيقة تقريباً.)



التشغيل بدرجة 8 مئوية

يمكن تشغيل التسخين الأولي في المناطق الباردة حيث تصل حرارة الغرفة لما تحت الصفر.

- 1 اضغط $\text{SET} + \text{CL} + \text{TEST}$ لمدة 4 ثوانٍ أو أكثر عند عدم تشغيل مكيف الهواء.
بعد فترة وجيزة، يومض جزء الشاشة، على النحو الموضح أدناه. تأكد من أن رقم الرمز هو [10].
- إذا كان رقم الرمز ليس [10]، اضغط زر TEST لمسح محتوى الشاشة، وكرر الإجراء من الخطوة الأولى. (بعد الضغط على زر TEST ، لن يقبل تشغيل جهاز التحكم عن بُعد لمدة 1 دقيقة تقريباً.)



(*) تتغير الشاشة وفقاً لرقم طراز الوحدة الداخلية)

2 في كل مرة تضغط على زر UNIT LOUVER ، يتم عرض رقم الوحدة الداخلية في مجموعة التحكم بالترتيب. اختر الوحدة الداخلية التي تم تغيير إعداداتها. في هذا الوقت، يمكن تحديد موقع الوحدة الداخلية التي تم تغيير إعداداتها لأن مروحة الوحدة الداخلية المختارة تكون قيد التشغيل.

3 حدد رقم الرمز [d1] بزرري درجة الحرارة $\text{▲} / \text{▼}$.

4 حدد مجموعة البيانات [0001] الوقت. $\text{▲} / \text{▼}$.


بيانات الضبط	إعداد تشغيل 8 درجات مئوية
0000	لا يوجد (ضبط المصنع)
0001	إعداد تشغيل 8 درجات مئوية

5 اضغط زر SET .
في هذه الأثناء، تنتهي الإعدادات عندما تتغير الشاشة من إنهاء إلى إضاءة.

6 اضغط زر TEST (تم تحديد الإعدادات)
عند الضغط على زر TEST تختفي الشاشة وتصبح الحالة حالة إيقاف عادي. (عند الضغط على زر TEST ، لن يقبل تشغيل جهاز التحكم عن بُعد لمدة 1 دقيقة تقريباً.)

مثال الإجراءات

إجراءات إعداد عنوان الدليل أثناء عمليات إيقاف التشغيل، غير الإعدادات. (أوقف تشغيل الوحدة.)




اضغط زر $\text{TEST} + \text{CL} + \text{SET}$ معا لمدة 4 ثوانٍ أو أكثر. بعد فترة وجيزة، يومض جزء الشاشة على النحو الموضح أدناه. تأكد من أن رقم الرمز هو [10]. إذا كان رقم الرمز ليس [10]، اضغط الزر TEST لمسح محتوى الشاشة، وكرر الإجراء من الخطوة الأولى. (بعد الضغط على زر TEST ، لن يقبل تشغيل جهاز التحكم عن بُعد لمدة 1 دقيقة تقريباً.) (مجموعة تحكم، يصبح رقم الوحدة الداخلية المعروض أولاً هو وحدة المشعب.)



في كل مرة تضغط على زر UNIT LOUVER ، يتم عرض رقم الوحدة الداخلية في مجموعة التحكم بالترتيب. اختر الوحدة الداخلية التي تم تغيير إعداداتها. في هذا الوقت، يمكن تحديد موقع الوحدة الداخلية التي تم تغيير إعداداتها لأن مروحة الوحدة الداخلية المختارة تكون قيد التشغيل.


٣

- حدد رقم الرمز [12] بزر TEMP / CL (درجة الحرارة). (رقم الرمز [12]: عنوان الخط)
- تغيير عنوان السطر من [3] إلى [2] مع الوقت TIME / CL أزرار.
- اضغط زر SET . في هذا الوقت، ينتهي الإعداد عندما يتغير العرض من الوميض إلى الإضاءة.



٤


- حدد رقم الرمز [13] بزر TEMP / CL (درجة الحرارة). (رقم الرمز [13]: عنوان الوحدة الداخلية)
- قم بتغيير عنوان الوحدة الداخلية من [3] إلى [2] بزر TIME / CL (الوقت).
- اضغط زر SET . في هذه الأثناء، تنتهي الإعدادات عندما تتغير الشاشة من إضاءة إلى إضاءة.



٥

- حدد رقم الرمز [14] بزر TEMP / CL (درجة الحرارة). (رقم الرمز [14]: مجموعة عنوان)
- تغيير بيانات SET من [0001] إلى [0002] زمن TIME / CL أزرار. (SET DATA [وحدة الرأس: 0001 [وحدة المتابعين: 0002])
- اضغط زر SET . في هذا الوقت، ينتهي الإعداد عندما يتغير العرض من الوميض إلى الإضاءة.

يظهر رقم الوحدة الداخلية قبل تغيير الإعدادات.




٦

- إذا كان هناك وحدة داخلية أخرى يراد تغيير إعداداتها، كرر الإجراءات من ٢ إلى ٥ لتغيير الإعدادات. عند انتهاء الإعداد أعلاه، اضغط على UNIT LOUVER لاختيار رقم الوحدة الداخلية قبل تغيير الإعدادات، حدد رقم الرمز [12]، [13]، [14] بالترتيب بزر TEMP / CL (درجة الحرارة)، ثم افحص المحتوى الذي تم تغييره.

فحص تغيير العنوان قبل التغيير:
[3-1] ← بعد التغيير: [2-2]

زر الضغط CL يسمح محتوياته
تم تغيير الإعداد
(في هذه الحالة، يتم تكرار الإجراء من ٢.)

يظهر رقم الوحدة الداخلية قبل تغيير الإعدادات.



٧

- فحص المحتوى الذي تم تغييره، اضغط زر TEST . (تم تحديد الإعدادات) عند الضغط على زر TEST تختفي الشاشة وتصبح الحالة حالة إيقاف عادي. (عند الضغط على زر TEST لن يقبل تشغيل جهاز التحكم عن بُعد لمدة 1 دقيقة تقريباً.) إذا لم يتم قبول العملية من جهاز التحكم عن بُعد حتى دقيقة واحدة أو أكثر مرات بعد الضغط على الزر، فيعتبر أن إعداد العنوان غير صحيح. في هذه الحالة، يجب إعداد العنوان التلقائي مرة أخرى TEST . لذلك كرر إجراء تغيير الإعداد من الإجراء ١.



■ مجموعة التحكم

مجموعة التحكم لنظام متعدد الوحدات

جهاز تحكم عن بُعد واحد يمكن أن يتحكم في ٨ وحدات داخلية بحد أقصى كمجموعة.

▼ مجموعة التحكم في نظام فردي



- لإجراء شبكة الأسلاك وطريقة نظام الخط الفردي (خط غاز تبريد مطابق)، اتبع "التوصيلات الكهربائية".
 - يجرى توصيل شبكة الأسلاك بين الخطوط وفق الإجراء التالي.
 - للوحدات الداخلية الأخرى بتوصيل الأسلاك (A / B) للوحدة الداخلية الموصلة بجهاز تحكم عن بُعد بمجموعات النهايات الطرفية (A / B) قم بتوصيل مجموعة النهايات الطرفية الداخلية للوحدة في جهاز التحكم عن بُعد السلكي.
 - عند تشغيل الإمداد بالطاقة الكهربائية، يبدأ إعداد العنوان تلقائي، ويومض جزء الشاشة الذي يشير إلى أن العنوان يتم إعداده في غضون ٣ دقائق تقريباً. أثناء إعداد العنوان التلقائي، لن يقبل تشغيل جهاز التحكم عن بُعد.
- الوقت المطلوب لإنهاء تحديد العنوان التلقائي هو حوالي ٥ دقائق.

المتطلبات

في بعض الحالات، من الضروري تغيير العنوان يدوياً بعد إعداد العنوان التلقائي وفقاً لتكوين النظام لعنصر مجموعة التحكم.


٤ اضغط على الزر ^{TEST} للعودة إلى شاشة العرض العادية.

بيانات الوحدة الداخلية	رقم الرمز	اسم البيانات
01	درجة حرارة الغرفة (جهاز التحكم عن بُعد)	
02	درجة حرارة الهواء الداخل للوحدة الداخلية (TA)	
03	درجة حرارة المبادل الحراري (الملف) للوحدة الداخلية (TCJ)	
04	درجة حرارة المبادل الحراري (الملف) للوحدة الداخلية (TC)	
F3	إجمالي ساعات علامة المرشح	

بيانات الوحدة الخارجية	رقم الرمز	اسم البيانات
60	درجة حرارة المبادل الحراري (الملف) للوحدة الخارجية (TE)	
61	درجة حرارة الهواء الخارجي (TO)	
62	درجة حرارة الهواء المفرغ من الضاغط (TD)	
63	درجة حرارة الهواء الداخل إلى الضاغط (TS)	
64	—	
65	درجة حرارة المشتت الحراري (THS)	
6A	التشغيل الحالي (١٠/×١)	
F1	إجمالي ساعات تشغيل الضاغط (١٠٠ × ساعة)	

■ وظيفة مراقبة مفتاح جهاز التحكم عن بُعد السلكي

هذه الوظيفة متاحة لطلب وضع مراقبة الخدمة من جهاز التحكم عن بُعد السلكي أثناء إجراء الاختبار لاكتساب درجات حرارة مستشعرات جهاز التحكم عن بُعد السلكي، والوحدة الداخلية، والوحدة الخارجية.



١ اضغط على الزرين ^{TEST} و ^{CL} في نفس الوقت لمدة ٤ ثوانٍ أو أكثر لطلب وضع مراقبة الخدمة.

٢ يضيء مؤشر مراقبة الخدمة ويتم عرض رقم مشعب الوحدة الداخلية أولاً. يتم عرض رقم الرمز ^{TEST}.

٣ اضغط زر درجة الحرارة **TEMP.** (▲ ▼), واختار رقم المستشعر، وما إلى ذلك (رقم الرمز) لمراقبته. (انظر الجدول أدناه).


٤ اضغط ^{UNIT LOUVER} (الجانب الأيسر من الزر)، واختار وحدة داخلية ليتم مراقبتها. يتم عرض درجات حرارة مستشعر الوحدات الداخلية والوحدة الخارجية لها في مجموعة التحكم.

إعداد أقل لجهاز التحكم عن بُعد


على لوحة دائرة جزء الاستقبال اللاسلكي. DIP لإعداد الضغط الساكن الخارجي، استخدم مفتاح لمزيد من التفاصيل. انظر دليل تعليمات طقم جهاز التحكم عن بُعد اللاسلكي. بالتعاقب، استخدم المفتاح الموجود على لوحة دائرة الكمبيوتر الدقيق للوحدة الداخلية كما هو موضح في الشكل والجدول التالي.

* بمجرد التغيير، يمكن تغيير الإعدادات "0001" و"0003" و"0006"، ولكن لإعادة الضبط على "0000"، من الضروري ضبط التغيير إلى الوضع الطبيعي (الافتراضي) واستخدام جهاز تحكم عن بُعد سلكي يُباع مُنفصلاً للكتابة على البيانات بالرقم "0000".

ON	OFF	ON	OFF	SW501-1
ON	ON	OFF	OFF	SW501-2
0006	0003	0001	0000 (ضبط المصنع)	بيانات الضبط



لإستعادة الإعدادات الافتراضية للمصنع لإعادة إعدادات مفتاح DIP إلى الإعدادات الافتراضية للمصنع، اضبط SW501-1 و SW501-2 على OFF (إيقاف)، ورم بتوصيل جهاز تحكم عن بُعد سلكي يباع على حدة، ثم اضبط بيانات رقم الرمز [5d] على "0000".



إعداد علامة المرشح

وفقا لحالة التركيب، يمكن تغيير وقت إضاءة علامة المرشح (إخطار تنظيف المرشح).
اتبع إجراء التشغيل الأساسي

(1) ← 2 ← 3 ← 4 ← 5 ← 6.

• معرفة رقم الرمز في الإجراء 3، حدد [01].

• بالنسبة لـ [SET DATA] (بيانات الضبط) في الإجراء 4 اختر SET DATA

(بيانات الضبط) لمعرفة مدة عرض علامة المرشح من الجدول التالي.

مدة عرض علامة المرشح	SET DATA
لا يوجد	0000
١٥٠ ساعة	0001
٢٥٠٠ ساعة (ضبط المصنع)	0002
٥٠٠٠ ساعة	0003
١٠٠٠٠ ساعة	0004

لضمان تأثير تدفئة أفضل

عندما يكون من الصعب الحصول على تدفئة مرضية نظرا لمكان تركيب الوحدة الداخلية أو بناء الغرفة، يمكن رفع درجة حرارة اكتشاف التدفئة. استخدم أيضا موزع أو جهاز آخر لتوزيع الهواء الساخن القريب من السقف. اتبع إجراء التشغيل الأساسي

(1) ← 2 ← 3 ← 4 ← 5 ← 6.

• معرفة رقم الرمز في الإجراء 3، حدد [06].


• بالنسبة لـ [SET DATA] (SET DATA) في الإجراء 4 اختر SET DATA (بيانات الضبط) لقيمة تغيير درجة الحرارة المكتشفة التي سيتم إعدادها من الجدول التالي.

بيانات الضبط	قيمة تغيير درجة الحرارة المكتشفة
0000	لا تغيير
0001	+١ مئوية
0002	+٢ مئوية (ضبط المصنع)
0003	+٣ مئوية
0004	+٤ مئوية
0005	+٥ مئوية
0006	+٦ مئوية

وضع توفير الطاقة

إجراء إعدادات وضع توفير الطاقة

* عند استخدام RAV-SP***2AT / RAV-SM***3AT أو أقدم، يتغير الإعداد المعروض، ولكن مستوى الطاقة الفعلي هو دائما "٧٥٪".



اضغط **SAVE** لمدة 4 ثوانٍ أو أكثر عند عدم تشغيل مكيف الهواء. **SETTING**، ومضات الرمز.

اضغط **UNIT LOUVER** (الجانب الأيسر من الزر)، واختر وحدة داخلية ليتم مراقبتها.


• في كل مرة يتم الضغط على الزر، الوحدة رقم. تغيير على النحو التالي:



تدحرجا وتدحرجا عرجوم لمعت

اضغط زري **TIME** (الوقت)، لضبط إعدادات مستوى الطاقة.

- كل ضغط على الزر تغيير مستوى الطاقة بنسبة ١٪ داخل النطاق من ١٠٠٪ إلى ٥٠٪.
- ضبط المصنع هو ٧٥٪.



إعداد مستوى الطاقة في وضع توفير الطاقة


4 اضغط زر **SET**.

5 اضغط زر **TEST** لإكمال الإعدادات.

٩ الضوابط القابلة للتطبيق


المتطلبات

- عند استخدام مكيف الهواء هذا لأول مرة، يستغرق تقريبا ٥ دقائق حتى يصبح جهاز التحكم عن بُعد متاحا بعد تشغيل الطاقة.
- هذا أمر طبيعي.
- عند تشغيل الطاقة لأول مرة بعد التركيب <
- يستغرق جهاز التحكم عن بُعد حوالي ٥ دقائق حتى يصبح متاحاً.



< عند تشغيل الطاقة للمرة الثانية (أو بعد ذلك) >

يستغرق جهاز التحكم عن بُعد حوالي ١ دقيقة حتى يصبح متاحاً.



- تم ضبط الإعدادات العادية عند شحن الوحدة الداخلية من المصنع.
- قم بتغيير إعدادات الوحدة الداخلية حسبما يكون مطلوباً.
- استخدم جهاز تحكم عن بُعد سلكي لتغيير الإعدادات.
- * لا يمكن تغيير الإعدادات باستخدام جهاز التحكم عن بُعد اللاسلكي، أو جهاز تحكم عن بُعد ثانوي، أو نظام عدم تحكم عن بُعد (لأجهزة التحكم عن بُعد المركزية فقط). لذا، قم بتركيب جهاز تحكم عن بُعد سلكي لتغيير الإعدادات.

■ الإجراءات الأساسية لتغيير الإعدادات


قم بتغيير الإعدادات أثناء عدم تشغيل مكيف الهواء.
(إيقاف مكيف الهواء قبل ضبط الإعدادات.)

⚠ تنبيه

اضبط رقم الرمز فقط الموضح في الجدول التالي: لا تضبط أي رقم رمز آخر.

إذا لم يكن رقم الرمز مضبوطاً، قد لا يكون من الممكن تشغيل مكيف الهواء أو قد تنتج مشكلة أخرى.


* تختلف الشاشات التي تظهر أثناء عملية الإعداد عن تلك الخاصة بجهاز التحكم عن بُعد السابقة (AMT21E, AMT31E). (هناك أكثر من رقم رمز)



١ اضغط مع الاستمرار على زر **TEST** وزر **TEMP** "درجة الحرارة" (معاً لمدة ٤ ثوانٍ أو أكثر). بعد فترة وجيزة، تومض الشاشة على النحو الموضح في الشكل أدناه. تأكد من أن رقم الرمز هو [01].


• إذا كان رقم الرمز ليس [01]، اضغط زر **TEST** لمسح محتوى الشاشة، وكرر الإجراء من البداية. (لأن يقبل جهاز التحكم عن بُعد التشغيل لبرهة من الزمن بعد الضغط على زر **TEST**.)
(أثناء تشغيل مكيف الهواء تحت مجموعة التحكم، يتم عرض "الجميع" أولاً.)

عند الضغط على **UNIT LOUVER** يكون رقم الوحدة الداخلية المعروضة عقب "الجميع" هي الوحدة الرئيسية.)



(* يتنوع محتوى العرض على الشاشة حسب طراز الوحدة الداخلية.)

٢ في كل مرة يتم الضغط فيها على الزر **UNIT LOUVER**، تتغير أرقام الوحدات الداخلية في مجموعة التحكم بشكل دائري. اختر الوحدة الداخلية لتغيير إعداداتها.
تعمل مروحة الوحدة المختارة وبيداً شق التهوية في التارجح. يمكن تأكيد إعدادات التغيير للوحدة الداخلية.



٣ حدد رقم الرمز [***] بزري درجة الحرارة "TEMP".
(▲ / ▼)

٤ حدد رقم الرمز [****] بزري درجة الحرارة "TIME".
(▲ / ▼)

٥ اضغط زر **SET** عندما يتغير العرض من وميض إلى مضيء، فإن الإعداد قد اكتمل.

• لتغيير إعدادات وحدة داخلية أخرى، كرر من الإجراء ٢.

• لتغيير إعدادات الوحدة الداخلية المختارة، كرر من الإجراء ٣.


استخدم زر **CL** لمسح الإعدادات. لعمل إعدادات بعد الضغط على زر

CL كرر من الإجراء ٢.

٦ عند إكمال الإعدادات، اضغط زر **TEST** لتحديد الإعدادات.

عند الضغط على زر **SETTING** يومض ثم يختفي محتوى الشاشة وينفذ مكيف الهواء وضع الإيقاف الطبيعي.

(عندما يومض **SETTING**، لن يقبل أي عملية من جهاز التحكم عن بُعد)



■ إعدادات الضغط الساكن الخارجي

إعداد تغيير الصنوبر استناداً إلى الثابت الخارجي ضغط القناة لتكون متصلة. لإعداد تغيير النقر، اتبع العملية الأساسية

الاجراء (١ ← ٢ ← ٣ ← ٤ ← ٥ ← ٦).

- حدد [5d] لرقم الرمز في الإجراء ٣.
- بالنسبة لـ SET DATA الخاصة بالإجراء ٤، حدد SET DATA للضغط الثابت الخارجي المراد إعداده من الجدول التالي.

< تغيير جهاز التحكم عن بُعد السلكية >




بيانات الضبط	الضغط الساكن الخارجي	0000
٥٠ باسكال	ضبط المصنع	0001
١٥٠ باسكال	—	0002
٨٠ باسكال	—	0003
٢٠٠ باسكال	—	0004
١٢٠ باسكال	—	0005
١٨٠ باسكال	—	0006
٢٥٠ باسكال	—	

تكون القائمة أعلاه عندما يكون SW501-1 و SW501-2 على وضع OFF (إيقاف).

توصيل الأسلاك

المتطلبات



- تأكد من توصيل الأسلاك بما يتطابق مع أرقام النهايات الطرفية. بسبب التوصيل غير الصحيح في حدوث خطأ.
- تأكد من تمرير الأسلاك من خلال جلية منفذ توصيل أسلاك الوحدة الداخلية.
- حافظ على هامش (حوالي ١٠٠ مم) على السلك لتعليق صندوق التحكم الكهربائي لأسفل في الصيانة، وما إلى ذلك.
- تتوفر دائرة منخفضة الجهد لجهاز التحكم عن بُعد السلكي. (لا توصل دائرة جهد عالٍ)



شبكة أسلاك جهاز التحكم عن بُعد

- قم بتعريه حوالي ٩ مم من السلك لتوصيله.
- يستخدم سلك ثنائي النواة غير قطبي لتوصيل جهاز التحكم عن بُعد. (أسلاك ٠,٥ مم إلى ٢,٠ مم)

شبكة أسلاك جهاز التحكم عن بُعد



التوصيلات الكهربائية

تحذير

- استخدم الأسلاك المحددة لتوصيل النهايات الطرفية للأسلاك، ثبتها بإحكام لمنع القوى الخارجية المطبقة على النهايات الطرفية من التأثير على النهايات الطرفية.
- قد يؤدي التوصيل أو التثبيت غير الكامل إلى حدوث حريق أو مشاكل أخرى.
- توصيل السلك الأرضي. (أعمال التأسيس)
- قد يتسبب التأريض غير المكتمل في التعرض لصدمة كهربائية.
- لا تقم بتوصيل أسلاك الأرضي بأنبوب الغاز أو أنبوب الماء، أو بممانعة الصواعق، أو السلك الأرضي للمهاقق.
- يجب تركيب الجهاز وفقاً للوائح شبكة الأسلاك الوطنية.
- قد يؤدي نقص قدرة الدائرة الكهربائية أو التركيب غير الكامل إلى حدوث صدمة كهربائية أو حريق.

تنبيه

- في حال تنفيذ شبكة أسلاك غير صحيحة/غير كاملة، قد يحدث حريق أو دخان كهربائي.
- تأكد من تركيب قاطع التسرب الأرضي الذي لا يتعثر بسبب الصدمة.
- في حال عدم تركيب قاطع تسرب أرضي، قد تحدث صدمة كهربائية.
- استخدم مشابك الكابل المرفقة مع المنتج.
- لا تتلف أو تكشط النواة الموصلة أو العازل الداخلي للطاقة وأسلاك الوصل البيني للنظام بينما تكون مقشرة.
- استخدم كابل التزويد بالتيار الكهربائي وأسلاك الربط البيني للنظام بالسلك المحدد، والنوع المحدد، وأجهزة الحماية المطلوبة.
- لا تقم مطلقاً بتوصيل طاقة قدرتها ٢٤٠-٢٢٠ فولت بمجموعات النهايات الطرفية (A)، (B)، وما إلى ذلك لشبكة أسلاك التحكم. (والإ، سيخفق النظام).
- قم بتوصيل الأسلاك الكهربائية بحيث لا تلمس جزء الأنبوب عالي الحرارة.
- قد تذوب الطبقة الخارجية مما يؤدي إلى وقوع حادث.


المتطلبات

- لشبكة أسلاك منبع التيار الكهربائي، يجب أن تتوافق مع اللوائح المحلية الخاصة بكل بلد.
- يجب أن يكون منبع التيار الكهربائي للوحدة الداخلية حصرياً ومنفصلاً عن منبع التيار الكهربائي للوحدة الخارجية.
- لشبكة أسلاك منبع التيار الكهربائي للوحدات الخارجية، اتبع دليل التركيب المرفق مع كل وحدة خارجية.
- بعد توصيل الأسلاك بمجموعة النهايات الطرفية، ضع سداة، وثبت الأسلاك بمشبك كابل.
- ضع خط أنابيب غاز التبريد وخط أسلاك التحكم في نفس الخط.
- لا تقم بتشغيل الطاقة للوحدة الداخلية حتى يكتمل تفريغ أنابيب غاز التبريد.

أسلاك

1. يوضح الشكل أدناه توصيلات شبكة الأسلاك خط منع التيار الكهربائي الداخلي بين الودعتين الداخلية والخارجية وبين الوحدات الخارجية وجهاز التحكم عن بُعد.
2. أزل الكابلات الزائدة غير المعزولة (الموصلات) بشرط عزل كهربائي. أفل ذلك بحيث لا تلمس أي أجزاء كهربائية أو معدنية.

الرسم البياني لشبكة الأسلاك



مواصفات الكهرباء والسلك

منبع التيار الكهربائي للمروحة	٢٤٠-٢٢٠ فولت-٣ نيوتن، ٥٠ هرتز ٢٢٠ فولت-٣ نيوتن، ٦٠ هرتز
أقصى تيار جار	٦A
تصنيف الصمامات	١٥A
منبع التيار الكهربائي لمروحة الوحدة الداخلية*	٢,٥ × ٣ مم ² أو أكثر (IEC 57 60245 أو H07RN-F)
مواصفات أسلاك الربط البيني*	١,٥ × ٤ مم ² أو أكثر (IEC 57 60245 أو H07RN-F)


* عدد الأسلاك × حجم السلك

شبكة أسلاك جهاز التحكم عن بُعد

شبكة أسلاك جهاز التحكم عن بُعد، وشبكة أسلاك ما بين وحدات جهاز التحكم عن بُعد	حجم السلك: ٢ × ٠,٥ إلى ٢,٠ مم ²
إجمالي طول سلك جهاز التحكم عن بُعد وشبكة أسلاك فيما بين وحدات جهاز التحكم عن بُعد = Ln ... + L2 + L1 + L	في حال النوع السلكي فقط حتى ٥٠٠ م
إجمالي طول شبكة أسلاك ما بين وحدات جهاز التحكم عن بُعد = Ln ... + L2 + L1	في حال النوع اللاسلكي المدمج حتى ٤٠٠ م
	حتى ٢٠٠ م

تنبيه

لا يمكن أن يكون سلك جهاز التحكم عن بُعد وسلك توصيل النظام متوازيين بحيث يلامس كل منهما الآخر ولا يمكن تخزينهما في نفس القناة. عند القيام بذلك، قد تحدث مشكلة في نظام التحكم نظراً للوضوءاء والعوامل الأخرى.




عملية العزل الحراري

- وضع العزل الحراري للأنيبيب كل على حدة في جانب السائل وجانب الغاز.
- للعزل الحراري للأنيبيب على جانب الغاز، تأكد من استخدام مادة مقاومة للحرارة بدرجة ١٢٠° درجة مئوية أو أعلى.
- لاستخدام أنبوب العزل الحراري المرفق، وضع العزل الحراري على جزء توصيل الأنيبيب للوحدة الداخلية بإحكام بدون وجود فجوة.

المتطلبات

- وضع العزل الحراري على جزء توصيل الأنيبيب للوحدة الداخلية بإحكام إلى النهاية بدون كشف الأنيبوب. (الأنيبوب المعرض للهواء الخارجي يسبب تسرب ماء.)
- لف العازل الحراري ووجه لأعلى (جانب السقف).



التفريغ

- أجرى التفريغ من منفذ شحن صمام الوحدة الخارجية باستخدام مضخة تفريغ. لمزيد من التفاصيل، اتبع دليل التركيب المرفق مع الوحدة الخارجية.
- لا تستخدم سائل التبريد محكم الغلق في الوحدة الخارجية لإجراء التفريغ.

المتطلبات

للأدوات مثل خرطوم الشحن، استخدم تلك المصنعة خصيصاً لسائل التبريد R410A.

كمية سائل التبريد التي يتم إضافتها

- بالإضافة لسائل تبريد، أضف سائل التبريد "R410A" المشار إليه في دليل تركيب الوحدة الخارجية المرفق.
- استخدم مقياس لشحن سائل التبريد بالكمية المحددة.

المتطلبات

- يؤدي شحن كمية زائدة أو كمية ضئيلة جدا من سائل التبريد إلى حدوث مشكلة في الضاغط.
- قم بشحن سائل التبريد بالكمية المحددة.
- ينبغي أن يكون الأفراد الذين يقومون بشحن سائل التبريد طول الأنيبوب وكمية سائل التبريد في لوحة F-GAS على الوحدة الخارجية. من الضروري تثبيت الضاغط وإصلاح عطل دورة التبريد.

فتح الصمام تماماً

افتح صمام الوحدة الخارجية تماماً. من المطلوب وجود مفتاح سداسي ٤ مم لفتح الصمام.

لمزيد من التفاصيل، انظر دليل التركيب المرفق مع الوحدة الخارجية.

فحص تسرب الغاز

تأكد بجهاز كشف تسرب أو ماء به صابون مما إذا كان هناك تسرب غاز أم لا، من جزء توصيل الأنيبيب أو غطاء الصمام.


المتطلبات

استخدم جهاز كشف تسرب مصنع حصرياً لغاز الهيدروفلوروكربون (R410A و R134a).

تنبيه

- لا تخدش السطح الداخلي للجزء المفlech عند إزالة الحواف المشوهة.
- عند معالجة التفلج في حالة الخدوش بالسطح الداخلي لجزء معالجة التفلج، سيؤدي ذلك إلى تسرب سائل التبريد.
- يُرجى التحقق من عدم حدوث خدش للجزء المفlech، أو تشوهه أو تدرج، أو تلف، وعدم وجود شرائح مُتبقية، أو مشكلات أخرى، بعد معالجة التفلج.
- لا تضع زيت ماكينة سائل تبريد على السطح المفlech.

- * في حال التوسيع بأداة توسيع تقليدية، اسحب للخارج بمقدار ٠,٥ مم تقريباً أكثر من التوسيع لسائل R22 للضغط لحجم التوسيع المحدد. مقياس الأنيبوب النحاسي مفيد لضبط حجم هامش الإسقاط.
- تم سد الغاز المدسود عند الضغط الجوي، لذا عند إزالة صامولة التوسيع، لن يكون هناك صوت "ضجيج". هذا أمر طبيعي وليس دالاً على مشكلة.
- استخدم مفتاحين ربط لتوصيل أنبوب الوحدة الداخلية.



العمل باستخدام مفتاح ربط مزدوج

- استخدم مستويات عزم الربط على النحو المدرج في الجدول أدناه.

عزم الربط (نيوتن*متر)	القطر الخارجي لأنبوب التوصيل (مم)
١٤ إلى ١٨	٦,٤
٣٤ إلى ٤٢	٩,٥
٤٩ إلى ٦١	١٢,٧
٦٣ إلى ٧٧	١٥,٩
٩٠,٥ إلى ١١٥	١٩,١

عزم الربط لتوصيلات أنبوب الطرف الواسع



قد يؤدي إجراء التوصيلات بشكل غير صحيح ليس فقط إلى تسرب غاز، ولكن يؤدي أيضاً إلى مشكلة في دورة التبريد.

قم بمحاذاة مراكز التوصيل وأحكام ربط صامولة التوسيع قدر الإمكان بأصابعك. ثم أحكم ربط الصامولة بمفتاح ربط ومفتاح عزم دوران على النحو الموضح في الشكل.


تنبيه

قد يؤدي إحكام الربط بعزم دوران مفرط إلى كسر الصامولة بناءً على ظروف التركيب.

<مخرج الهواء>



<مدخل الهواء>



٧ شبكة أنابيب سائل التبريد

■ أنابيب سائل التبريد

- استخدم العناصر التالية لأنابيب سائل التبريد.
الخامة: أنابيب نحاسية فوسفورية منزوعة الأكسجين غير ملحومة.
سمك الجدار: ٠.٨ مم أو أكثر لـ Ø١٢.٧ مم (C1220T-0) أو أكثر لـ Ø٢٨.٦ مم (C1220T-1/2H).
لا تستخدم الأنابيب النحاس التي يقل سمك جدارها عن هذا السمك.
- تختلف صامولة الطرف الواسع وأعمال التوسيع أيضا عن تلك الخاصة بغاز التبريد التقليدي.
- أخرج صامولة الطرف الواسع الملحقة بالوحدة الرئيسية لمكيف الهواء، واستخدمها.

المتطلبات

عندما يكون أنبوب غاز التبريد طويلاً، زود دعائم المساندة عند فواصل إلى ٢.٥ م لإحكام أنبوب غاز التبريد. وإلا، قد يتولد صوت غير طبيعي.

⚠ تنبيه

- أربع نقاط مهمة ينبغي مراعاتها في أعمال الأنابيب
- لا يُسمح بالوصلات المفلجة والوصلات الميكانيكية القابلة لإعادة استخدام في الداخل. عند إعادة استخدام الموصلات الميكانيكية في الداخل، يجب تجديد الأجزاء المانعة للتسرب. عند إعادة استخدام الموصلات المفلجة في الداخل، يجب إعادة تصنيع الجزء المفلج.
 - أحكام التوصيل (بين الأنابيب والوحدة)
 - قم بتفريغ الهواء في أنابيب التوصيل باستخدام مضخة فراغية.
 - أفحص تسرب الغاز. (نقاط التوصيل)

■ حجم الأنابيب

حجم الأنابيب (مم)	
جانب الغاز	جانب السائل
١٩,٠٥ قطر	٩,٥٢ قطر

■ توصيل أنبوب غاز التبريد بجانب السائل

اختلاف طول وارتفاع الأنابيب المسموح به

يختلف وفقا للوحدة الخارجية.
لمزيد من التفاصيل، انظر دليل التركيب المرفق مع الوحدة الخارجية.


■ توصيل شبكة أنابيب سائل التبريد

التوسيع

- قطع الأنبوب بقاطع أنابيب.
- أزل الحواف الخشنة تماماً.
- قد تسبب الحواف الخشنة المتبقية تسرب غاز.
- أدخل صامولة توسيع في الأنبوب، وقم بتوسيع الأنبوب.
- حيث إن أحجام التوسيع لغاز R410A تختلف عن تلك الخاصة بغاز R22، يوصى باستخدام أدوات التوسيع المصنعة حديثاً لغاز R410A.
- ومع ذلك، يمكن استخدام الأدوات التقليدية بتعديل هامش الإسقاط للأنبوب النحاسي.


هامش الإسقاط في التوسيع: B (الوحدة: مم)

الأداة التقليدية المستخدمة	الأداة المستخدمة	القطر الخارجي للأنبوب النحاسي
١.١ إلى ٠.٥	١.١ إلى ٠.٥	٩.٥، ٦.٤
٢.٠ إلى ١.٥	١.١ إلى ٠.٥	١٩.١، ١٥.٩، ١٢.٧




حجم قطر التوسيع: A (الوحدة: مم)

القطر الخارجي للأنبوب النحاسي	A
٦.٤	٩.٥
٩.٥	١٣.٢
١٢.٧	١٦.٦
١٥.٩	١٩.٧
١٩.١	٢٤.٠



حجم الهواء القياسي: ٣,٦٠٠ م^٣/الساعة



٦ تصميم القنوات

تصميم القنوات

١ لمنع الدوائر القصيرة، قم بتصميم قناة العمل بحيث تكون فتحات الدخول والخروج غير مجاورة لبعضها البعض.


٢ لا تحتوي الوحدة الداخلية على مرشح هواء مدمج.

قم دائما بتركيب مرشح الهواء (يُباع محليا) في موقع يسمح بسهولة الصيانة، مثل وراء شبكة المدخل. (في حال عدم تركيب مرشح هواء، سيجمع الغبار في المبادل الحراري، مما قد يتسبب في عطل مكيف الهواء أو حدوث تسرب به.)

تنظرة عامة على توصيل القنوات


ملاحظة

تُباع الأجزاء باستثناء وحدة تكييف الهواء محليا.



■ متطلبات إزالة الكرتون الخاص بالنقل

• تأكد من إزالة كرتون الحماية الخاص بالنقل المُدخل في الفجوة بين الكابينة العليا والمبادل الحراري قبل تركيب الوحدة الداخلية.




٥ عمل أنابيب التصريف

⚠ تنبيه

حسب دليل التركيب، أجري أعمال أنابيب التصريف بحيث يتم تصريف المياه بشكل صحيح، وتطبيق العزل الحراري حتى لا يتسبب في سقوط ندى. قد يؤدي القيام بأعمال الأنابيب بشكل غير مناسب إلى تسرب مياه في الغرفة وإتلاف الأثاث.

- زود أنابيب تصريف الوحدة الداخلية مع العزل الحراري المناسب.
- وفر منطقة يمكن فيها توصيل الأنابيب بالوحدة الداخلية بعازل حراري مناسب. يتسبب العزل الحراري غير المناسب في تكوين تكثيف.
- يجب أن يكون أنبوب التصريف منحدرًا لأسفل (بزواوية 1/100 أو أكثر) ولا تحرك الأنابيب لأعلى أو أسفل (شكل قطري) أو اسمح له بتكوين تضخم. قد يؤدي القيام بذلك إلى أصوات غير طبيعية.
- اقصر طول أنبوب التصريف المتقاطع على ٢٠ م أو أقل. في حال الأنابيب الطويل، قم بتوفير دعائم مساندة بطول ١,٥ م إلى ٢ م من أجل منع التموج.
- قم بتركيب أنبوب التجميع على النحو الموضح في الشكل أدناه.
- لا توفر أي فتحات هواء. وإلا، تدفق ماء التصريف، متسببًا في تسرب المياه.
- لا تسمح باستخدام القوة في منطقة التوصيل مع أنبوب التصريف.



■ نافذ مادة الأنابيب وحجمها والعازل

يتم شراء المواد التالية الخاصة بأعمال الأنابيب وعملية العزل محليًا.


مادة الأنابيب	أنبوب كلوريد فينيل صلب VP2٥ (القطر الخارجي الطبيعي ٣٢ مم)
العازل	رغوة بولي إيثيلين، السمك: ١٠ مم أو أكثر

■ توصيل أنبوب التصريف

أدخل خرطوم تصريف مرن في أنبوب التصريف العلوي بالوحدة الأساسية إلى أقصى حد ممكن. ثبته برباط خرطوم.

المتطلبات

علق خرطوم التصريف المرن باستخدام رباط الخرطوم بدون استخدام مادة لاصقة.



٤ التركيب




تنبيه

- الامتثال الصارم للقواعد التالية لمنع إلحاق ضرر بالوحدات الداخلية والإصابات البشرية.
- لا تضع أي شيء ثقيل على الوحدة الداخلية. (حتى لو كانت الوحدات مغلقة)
- احمل الوحدة الداخلية وهي مغلقة إذا أمكن. وفي حال حمل الوحدة الداخلية وهي غير مغلقة بحكم الضرورة، تأكد من استخدام قطعة قماش التخزين المؤقت، وما إلى ذلك حتى لا يلحق ضرر بالوحدة.
- لتحريك الوحدة الداخلية، امسك من معادن التعليق (٤ مواقع) فقط.
- لا تستخدم القوة مع الأجزاء الأخرى (أنابيب غاز التبريد، أو مجمع التصريف، أو أجزاء الرغوية، أو أجزاء الراتنج، وما إلى ذلك).
- يحمل العبوة شخصين أو أكثر، ولا يتم ربطها برباط بلاستيك في مواقع غير الموقع المحدد.
- لتثبيت مادة عزل الاهتزاز على المسامير المعلقة، تأكد من أنها لا تزيد من اهتزاز الوحدة.

■ الأبعاد الخارجية

(الوحدة: مم)



■ فتح فتحات في سقف وتركيب مسامير التعليق

- النظر إلى شبكة الأنابيب / الأسلاك بعد تعليق الوحدة عند تحديد موقع تركيب وتوجه الوحدة الداخلية.
- بعد تحديد مكان تركيب الوحدة الداخلية، افتح السقف وقم بتركيب مسامير التعليق.
- بالنسبة لأبعاد ميل مسامير التعليق، المنظر الخارجية.
- عند وجود سقف بالفعل، ضع أنبوب التصريف، وأنبوب التبريد، وأسلاك توصيل الوحدة الداخلية / الوحدة الخارجية، وأسلاك جهاز التحكم عن بُعد في مواقع توصيلاتهم قبل تعليق الوحدة الداخلية.

قم بشراء ورد مسامير التعليق والصواميل لتركيب الوحدة الداخلية (ليست مرفقة).

قطعة ٤	W3/8 أو M10	مسمار تعليق
قطعة ١٢	W3/8 أو M10	صامولة
قطعة ٨	M10	وردة

تركيب مسمار التعليق

استخدم مسامير تعليق M10 (٤ قطع، تباع محلياً). المطابقة مع الهيكل الحالي، اضبط الميل وفقاً للحجم في المنظر الخارجي للوحدة على النحو الموضح.

بلاطة خرسانية جديدة

قم بتركيب المسامير التي بها دعائم إدخال أو مسامير التثبيت.

هيكل إطار صلب

استخدم الزوايا الموجودة أو قم بتركيب زوايا دعم جديدة.

بلاطة خرسانية موجودة


استخدم مثبت فتحة، أو قابس فتحة، أو مسامير فتحة.

■ تركيب الوحدة الخارجية

معالجة السقف



- يختلف السقف وفقاً لهيكل البناء.
- لمزيد من التفاصيل، استشر أخصائي تشييد أو مقاول تشطيبات داخلية.
- إنهاء العملية بعد إزالة لوحة السقف، من المهم تعزيز أساس (إطار) السقف والحفاظ على المستوى الأفقي للسقف المثبت بشكل صحيح من أجل منع اهتزاز لوحة السقف.

- ضع الصواميل والورد المسطحة مقياس M10 في مسامير التعليق.
- ضع الورد فوق وتحت دعامة تعليق الوحدة الداخلية لتعليق الوحدة الداخلية.
- تأكد من أن الأربع جوانب أفقية باستخدام مقياس مستوى (الدرجة الأفقية: في حدود ٥ مم)



المتطلبات

- علق الوحدة في وضع أفقي.
- عند تعليق الوحدة بميل، قد يتسبب ذلك في فيض الصرف.
- قم بتركيب الوحدة في حدود الأبعاد الواردة في الشكل أدناه.
- استخدم مقياس مستوى للتأكد مما إذا كانت الوحدة معلقة أفقياً أم لا.



■ التركيب في جو عالي الرطوبة

في بعض الحالات، بما في ذلك موسم الأمطار، وخاصة داخل السقف، قد يصبح الجو عالي الرطوبة (درجة حرارة نقطة الندى: ٢٣° درجة مئوية أو أعلى).

١. التركيب داخل سقف به بلاط على السطح
 ٢. التركيب داخل سقف سطح مسقف
 ٣. التركيب في مكان يكون فيه داخل السقف مستخدم كمسار لدخول الهواء النقي
 ٤. التركيب في مطبخ
- في الحالات المذكورة أعلاه، بالإضافة إلى ذلك ضع عازل حرارة على جميع مواضع مكيف الهواء، والتي تتصل بجو عالي الرطوبة. في هذه الحالة، قم بترتيب اللوحة الجانبية (منفذ الفحص) بحيث يتم إزالتها بسهولة.
 - ضع أيضاً عازل حراري كافٍ على القناة وجزء توصيل القناة.

حالات اختبار التكييف

[المرجع]



جانب الوحدة الداخلية:	درجة حرارة البصيلة الجافة ٢٧° مئوية
حجم الهواء:	درجة حرارة البصيلة الرطبة ٢٤° مئوية
	حجم هواء منخفض، التشغيل لمدة ٤ ساعات

■ مساحة التركيب



(الوحدة: مم)

حافظ على المساحة الكافية المطلوبة لأعمال التركيب أو الصيانة.

المساحة المطلوبة للتركيب والصيانة



عند إرفاق حقيبة أدوات مرشح يدوم مدى الحياة (يباع على حدة)



١* في حال وجود مساحة كافية تحت الوحدة (أكثر من ١٠٠٠ مم) لا يكون باب الصيانة (فتحة السقف) ضرورياً.

■ إعداد وقت إضاءة علامة تنظيف المرشح

يمكن تغيير ضبط وقت إضاءة علامة المرشح (إخطار تنظيف المرشح) على جهاز التحكم عن بُعد وفقاً لظروف التركيب. لطريقة الإعداد، انظر "إعداد علامة المرشح" في أجهزة التحكم القابلة للتطبيق الواردة في هذا الدليل.

٢ أجزاء الملحقات

أسماء الأجزاء	الكمية	الشكل	الإستخدام
دليل التركيب	١	هذا الدليل	(سلمه إلى العميل)
سلمه إلى العميل	١		(تأكد من تسليمه إلى العميل)
أنبوب عزل الحرارة	٢	 (٦٤×٢٠٠×٢٠٠)	للعزل الحراري لجزء توصيل أنبوب الغاز وأنبوب السائل
وردة	٨		لتعليق الوحدة
رباط الخرطوم	١		لتوصيل أنبوب التصريف
خرطوم مرن	١		لتعديل مركز أنبوب التصريف
عازل حرارة	١	 (١٠٤×٣٠٠×٢٢٠)	للعزل الحراري لجزء توصيل أنابيب التصريف
مادة سد	٣	 (٣٤×٤٥×٤٥)	لقفل منفذ توصيل الأسلاك

٣ اختيار مكان التركيب

تجنب التركيب في الأماكن التالية

اختار مكان للوحدة الداخلية يدور فيه الهواء البارد والدافئ بشكل متساوي.
تجنب التركيب في أنواع الأماكن التالية.

- المنطقة المالحة (المنطقة الساحلية).
- الأماكن التي بها أجواء حمضية أو قلووية (مثل المناطق التي بها ينابيع ساخنة، والمصانع التي تصنع مواد كيميائية أو مواد صيدلانية، والأماكن التي سيتم امتصاص هواء العادم من المصادر من أجهزة الاحتراق إلى وحدة).
- قد يؤدي القيام بذلك تآكل المبادل الحراري (أجنحة الألمنيوم وأنابيب النحاس) والأجزاء الأخرى.
- المواقع التي بها أجواء ذات ضباب زيت قطع أو أنواع أخرى من زيت الماكينات. قد يؤدي القيام بذلك إلى تآكل المبادل الحراري، وتولد ضباب ناجم عن انسداد المبادل الحراري، وتلف القطع البلاستيك، وتقتصر العوازل الحرارية، ومشاكل أخرى من هذا القبيل.
- الأماكن التي يوجد بها غبار حديد أو غبار معادن أخرى. إذا التصق غبار الحديد أو المعادن الأخرى أو تجمع داخل مكيف الهواء، قد يحترق الجهاز على الفور أو يحدث حريق.
- الأماكن التي يتشكل فيها أبخرة من الزيوت الغذائية (مثل المطابخ حيث تستخدم زيوت الطعام). قد تتسبب المرشحات المسدودة في تدهور أداء مكيف الهواء، وتكوين التكتيف، وتلف قطع البلاستيك، ومشاكل أخرى من هذا القبيل.
- الأماكن القريبة من العوايق مثل فتحات التهوية أو تجهيزات الإضاءة حيث سيتم إعاقة تدفق الهواء الخارج (قد يؤدي إعاقة تدفق الهواء إلى تدهور في أداء مكيف الهواء أو إيقاف الوحدة).
- الأماكن التي يستخدم فيها مولد طاقة كهربائية داخل المنزل للإمداد بالتيار الكهربائي. قد يتقلب تردد وجهد خط التيار الكهربائي، وقد لا يعمل مكيف الهواء بشكل صحيح نتيجة لذلك.
- على الشاحنات الرافعة، والسفن، ووسائل النقل المتحركة الأخرى.
- لا يجب استخدام مكيفات الهواء للتطبيقات الخاصة (مثل تخزين المواد الغذائية أو النباتات أو الآلات الدقيقة أو الأعمال الفنية).
- (قد تقل جودة المواد المخزنة.)
- المواقع التي تتولد فيها ترددات عالية (بواسطة المعدات العاكسة، أو مولدات الكهرباء في المنزل، أو المعدات الطبية، أو معدات الاتصالات).
- (قد يؤثر حدوث خلل أو مشكلة في التحكم في مكيف الهواء أو ضوضاء سلبا على الجهاز.)
- الأماكن التي يوجد فيها أي شيء مركب تحت الوحدة من شأنه أن يتعرض لخطر البلل. (إذا انسدت التصريف أو عند زيادة الرطوبة عن ٨٠٪، سوف تسقط نقط تكثيف من الوحدة الداخلية، بما قد يتسبب في ضرر على أي شيء تحت الجهاز.)
- في حالة نوع النظام اللاسلكي، الغرف التي بها إضاءة من نوع العاكس الفلوريسنت أو المواقع المعرضة لأشعة الشمس المباشرة.
- (قد لا يتم الشعور بالإشارات الصادرة من جهاز التحكم عن بُعد اللاسلكية.)
- الأماكن التي يستخدم فيها مذبذبات عضوية.
- لا يمكن استخدام مكيفات الهواء لتبريد حمض الكربونيك المسال أو في المصانع الكيماوية.
- الأماكن القريبة من الأبواب أو النوافذ التي قد يتلامس فيها مكيف الهواء مع الوحدة الخارجية مرتفعة الحرارة أو عالية الرطوبة.
- (قد يحدث تكثيف نتيجة لذلك.)
- الأماكن التي يستخدم فيه رذاذ خاص كثيرا.
- الأماكن سيئة التهوية.

⚠️ تنبيه

تركيب مكيف الهواء ذو غاز التبريد الجديد

• يعتمد مكيف الهواء هذا غاز الهيدروفلوروكربون الجديد (R410A) الذي لا يدمر طبقة الأوزون.

- خصائص غاز التبريد R410A هي: سهولة امتصاص الماء، أو غشاء الأكسدة، أو الزيت، وضغطه أعلى بمقدار ١,٦ مرة تقريبا من غاز التبريد R22. بالإضافة إلى تغيير غاز التبريد الجديد، تم تغيير زيت التبريد. لذا، أثناء أعمال التركيب، تأكد من عدم دخول الماء، أو الغبار، أو غاز التبريد السابق، أو زيت التبريد في دائرة التبريد.
- لمنع شحن غاز تبريد وزيت تبريد غير صحيح، تم تغيير أحجام أجزاء التوصيل لمنفذ الشحن بالوحدة الرئيسية وأدوات التركيب عن غاز التبريد التقليدي.
- بناء على ذلك، يطلب أدوات حصرية لغاز التبريد الجديد (R410A).
- لتوصيل الأنابيب، استخدم أنابيب جديدة ونظيفة مصممة للغاز R410A، ويرجى الحرص بحيث لا يدخل مياه أو غبار.

لفصل الجهاز من مصدر الإمداد بالتيار الرئيسي.

- يجب توصيل هذا الجهاز بمصدر إمداد بتيار رئيسي بواسطة مفتاح به فاصل اتصال سمكه ٣ مم على الأقل.

يجب استخدام قفازات التركيب (يمكن استخدام جميع الأنواع) لخط منبع التزويد بالتيار الكهربائي في مكيف الهواء هذا.

(*) ارجع إلى "تعريف أخصائي التركيب المؤهل أو فني الصيانة المؤهل".

- قم بتركيب قاطع الدائرة في مكان يمكن للوكيل الوصول إليه بسهولة.
- لتركييب قاطع الدائرة في الخارج، قم بتركيب قاطع الدائرة المصمم للاستخدام في الخارج.
- يجب عدم تمديد سلك الطاقة تحت أي ظرف من الظروف. قد تتسبب مشاكل التوصيل في الأماكن التي يمتد فيها السلك في حدوث دخان و/أو حريق.
- يجب إجراء أعمال شبكة الأسلاك الكهربائية وفقاً للقانون واللوائح المجتمعية ووفقاً لدليل التركيب.
- فقد يؤدي عدم القيام بذلك إلى لصعق كهربائي أو ماس كهربائي.

التشغيل التجريبي

- قبل تشغيل مكيف الهواء بعد إنهاء العمل، تأكد من أن إغلاق غطاء صندوق التحكم الكهربائي للوحدة الداخلية أو لوحة الصيانة للوحدة الخارجية، واضبط قاطع الدائرة على وضع ON (تشغيل). قد تتلقى صدمة كهربائية إذا تم تشغيل الطاقة دون إجراء هذه التأكيدات أولاً.
- إذا كان هناك أي نوع من المشاكل (مثلاً ظهور خطأ ما، أو رائحة حريق، أو أصوات غير طبيعية، أو أخفق مكيف الهواء في التبريد أو التدفئة، أو كان هناك تسرب مياه) في مكيف الهواء، لا تلمس مكيف الهواء بنفسك ولكن اضبط قاطع الدائرة على وضع OFF (إيقاف)، واتصل بفني صيانة مؤهل. اتخذ الخطوات اللازمة لضمان عدم تشغيل الطاقة (عن طريق وضع علامة "خارج الخدمة" بالقرب من قاطع الدائرة، على سبيل المثال) حتى يصل فني صيانة مؤهل. قد يتسبب الاستمرار في استخدام مكيف الهواء أثناء وجود مشكلة في حدوث مشاكل ميكانيكية أو يؤدي ذلك إلى حدوث صدمات كهربائية أو متاعب أخرى.
- بعد الانتهاء من العمل، استخدم جهاز اختبار عزل (جهاز ميجر بقوة ٥٠٠ فولت) للتحقق من أن المقاومة هي ١ ميجا أوم أو أكثر بين جزء الشحن والجزء المعدني لغير الشحن (الجزء الأرضي). إذا كانت قيمة المقاومة منخفضة، تحدث كارثة مثل تسرب أو صدمة كهربائية للمستخدم.
- عند الانتهاء من أعمال التركيب، تأكد من عدم وجود تسرب غاز تبريد، وتأكد من مقاومة العزل وتصريف المياه. ثم قم بالتشغيل التجريبي للتأكد من أن مكيف الهواء يعمل بشكل صحيح.

التوضيحات المقدمة للمستخدم

- فور الانتهاء من أعمال التركيب، أخبر المستخدم بمكان قاطع الدائرة. إذا كان المستخدم لا يعرف مكان قاطع الدائرة، لن يتمكن من إيقافه في حال حدوث مشكلة في مكيف الهواء.
- بعد انتهاء أعمال التركيب، اتبع دليل المالك لتشرح للعميل كيفية استخدام وصيانة الوحدة.

النقل

- لا يسمح سوى لأخصائي تركيب مؤهل (*) أو فني صيانة مؤهل (*) بنقل مكيف الهواء. من الخطر نقل مكيف الهواء بواسطة شخص غير مؤهل حيث قد يؤدي ذلك إلى حدوث حريق، أو صدمات كهربائية، وإصابة، أو تسرب مياه، أو ضوضاء و/أو اهتزاز.
- عند إجراء عمليات الضخ السفلي، أغلق الضاغظ قبل فصل أنبوب غاز التبريد.
- قد يؤدي إزالة أنبوب غاز التبريد مع ترك صمام الخدمة مفتوح والضاغط في حالة تشغيل إلى سحب الهواء والغاز إلى الداخل، مما قد يتسبب في وصول الضغط داخل دورة التبريد إلى مستوى عال بشكل غير طبيعي، الأمر الذي ينتج عنه حدوث انفجار أو إصابة أو مشاكل أخرى.

- قبل تنظيف المرشح أو الأجزاء الأخرى للوحدة الخارجية، اضبط قاطع الدائرة على OFF (إيقاف) دون فشل، وضع علامة "جاري العمل" بالقرب من قاطع الدائرة قبل الشروع في العمل.
- قبل بدء العمل على ارتفاعات، ضع علامة في مكان واضح بحيث لا يقترب أحد من موقع العمل، قبل الشروع في العمل. قط تسقط أجزاء وأشياء أخرى من فوق، وربما تؤدي إلى إصابة أي شخص أدناها. وأثناء تنفيذ العمل، ارتدي خوذة للحماية من الأشياء الساقطة.
- لا تستخدم سائل تبريد غير سائل التبريد R410A.
- فيما يتعلق بنوع سائل التبريد، تحقق من وجوده في الوحدة الخارجية.
- غاز التبريد المستخدم في مكيف الهواء هذا، اتبع دليل التركيب المرفق مع الوحدة الخارجية.
- يجب نقل مكيف الهواء في وضع مستقر. فإذا انكسرت أي قطعة من المنتج، اتصل بالتاجر.
- يجب نقل مكيف الهواء في حالة مستقرة. في حالة كسر أي جزء من المنتج، اتصل بالوكيل.
- عند وجوب نقل مكيف الهواء باليد، يجب أن يحمله شخصان أو أكثر.
- لا تحرك أو تصلح أي وحدة بنفسك. هناك جهد عالٍ داخل الوحدة. قد تحصل لك صدمة كهربائية عند إزالة غطاء الوحدة الرئيسية.
- هذا الجهاز مصمم للاستخدام بواسطة الخبراء أو المستخدمين المدربين في المحلات، أو الصناعات الخفيفة، أو للأغراض التجارية بواسطة الأشخاص العاديين.

اختيار مكان التركيب

- عند تركيب مكيف الهواء في غرفة صغيرة، اتخذ تدابير مناسبة لضمان عدم تجاوز تركيز تسرب غاز التبريد في الغرفة المستوى الحرج.
- لا تقم بتركيب الجهاز في موقع يمكن حدوث تسرب غاز قابل للاشتعال فيه. إذا تسرب الغاز وتتراكم حول الوحدة، قد تشعل وتسبب حريق.
- لنقل مكيف الهواء، ارتدي أحذية بها قبعات واقية لأصابع القدمين.
- لنقل مكيف الهواء، لا تحمل من الأربطة حول كرتونة التعبئة والتغليف. قد تجرح نفسك إذا انكسرت الأربطة.
- قم بتركيب الوحدة الداخلية فوق مستوى الأرض بمسافة ٢,٥ متر وإلا فإن المستخدم قد يصاب أو يتلقى صدمات كهربائية إذا أدخل أصابعه أو أشياء أخرى في الوحدة الداخلية أثناء تشغيل مكيف الهواء تشغيل.
- لا تضع أي جهاز احتراق في مكان يتعرض فيه مباشرة لرياح مكيف الهواء، وإلا قد يسبب احتراق غير كامل.

التركيب

- عند تعليق الوحدة الداخلية، يجب استخدام مسامير التعليق المحددة (M10 أو W3/8) والصواميل (M10 أو W3/8).
- قم بتركيب مكيف الهواء بشكل آمن في مكان يمكن أن تتحمل فيه القاعدة الوزن على نحو كاف. إذا كانت القوة غير كافية، قد تسقط الوحدة مما يؤدي إلى إصابة.
- اتبع التعليمات الواردة في دليل التركيب لترتيب تركيب مكيف الهواء. فقد يؤدي عدم اتباع هذه التعليمات إلى سقوط أو وقوع المنتج أو حدوث ضوضاء، أو اهتزاز، أو تسرب مياه، أو غيرها من المشاكل.
- قم بأعمال التركيب المحددة للحماية من إمكانية الرياح العاتية والزلازل. إذا لم يتم تثبيت مكيف الهواء بشكل مناسب، قد تسقط أو تقع الوحدة، مما يؤدي إلى وقوع حادث.

- إذا حدث تسرب لغاز التبريد خلال أعمال التركيب، قم بتهوية الغرفة على الفور. وإذا اتصل غاز التبريد المتسرب بنار، قد يتولد غاز سام.
- استخدم رافعة شوكية لحمل وحدتي مكيف الهواء، واستخدم ونش أو رافعة في تركيبهما.
- يجب أن تكون قناة الشفط أطول من ٨٥٠ مم.
- يجب ارتداء الخوذة لحماية رأسك من الأشياء الساقطة. وخاصة، عند العمل تحت فتحة فحص، يجب ارتداء الخوذة لحماية رأسك من الأشياء الساقطة من الفتحة.

أنابيب غاز التبريد

- قم بتركيب أنبوب غاز التبريد بشكل آمن أثناء أعمال التركيب قبل تشغيل مكيف الهواء. إذا تم تشغيل الضاغطة والصمام مفتوح وبدون أنبوب غاز التبريد، يمتص الضاغطة الهواء ويزيد ضغط دورات التبريد، مما قد يتسبب في حدوث إصابة.
- أحكم ربط صامولة الطرف الواسع مستخدماً مفتاح ربط عزم دوران وفقاً للطريقة المحددة.
- قد يتسبب زيادة إحكام ربط صامولة الطرف الواسع في حدوث صدع في الصامولة بعد فترة طويلة، مما قد يؤدي إلى تسرب غاز التبريد.
- بعد أعمال التركيب، تأكد من عدم تسرب غاز التبريد. إذا تسرب غاز التبريد في الغرفة وتدفق بالقرب من مصدر نار، مثل موقد الطبخ، قد يتولد غاز ضار.
- عند تركيب أو نقل مكيف الهواء، اتبع التعليمات الواردة في دليل التركيب وطهر الهواء تماماً بحيث لا تختلط غازات أخرى غير غاز التبريد في دورة التبريد. قد يؤدي عدم تطهير الهواء تماماً في عطل مكيف الهواء.
- يجب استخدام غاز النيتروجين لاختبار إحكام الهواء.
- يجب أن يكون خرطوم الشحن موصلاً بطريقة بحيث لا يكون مرتخياً.

شبكة الأسلاك الكهربائية

- لا يسمح سوى لأخصائي تركيب مؤ (*١) هل أو فني صيانة مؤهل بتنفيذ (*١) الأعمال الكهربائية لمكيف الهواء.
- ولا يجب إجراء فرد غير مؤهل لهذه الأعمال، تحت أي ظرف من الظروف لأن عدم إجراء هذه الأعمال بشكل صحيح قد يؤدي إلى حدوث صدمة كهربائية و/أو تسرب كهربائي.
- لتوصيل الأسلاك الكهربائية، أو إصلاح الأجزاء الكهربائية، أو القيام بأعمال كهربائية أخرى، ارتد قفازات توفر حماية لفني الكهرباء وحماية من الحرارة، وحذاء عازل، وملابس توفر حماية من الصدمات الكهربائية. قد يؤدي عدم ارتداء هذه الملابس الواقية إلى حدوث صدمات كهربائية.
- استخدم شبكة الأسلاك التي تفي بالموصفات الواردة في دليل التركيب والشروط الواردة في الأنظمة والقوانين المحلية. قد يؤدي استخدام شبكة الأسلاك التي لا تفي بالموصفات إلى حدوث صدمات كهربائية، أو تسرب كهربائي، أو دخان، و/أو حريق.
- توصيل السلك الأرضي. (أعمال التأريض)
- قد يتسبب التأريض غير المكتمل في التعرض لصدمة كهربائية.
- لا تقم بتوصيل أسلاك الأرضي بأنبوب الغاز أو أنبوب الماء، أو بمناعة الصواعق، أو السلك الأرضي للهاتف.
- بعد الانتهاء من أعمال الإصلاح أو النقل، تأكد من أن أسلاك الأرضي مربوطة بشكل صحيح.
- قم بتركيب قاطع دائرة يفي بالموصفات الواردة في دليل التركيب والشروط الواردة في الأنظمة والقوانين المحلية.

■ علامات التحذير الموجودة على وحدة مكيف الهواء

الوصف	علامة التحذير
تحذير خطر الإصابة بصدمة كهربائية أفضل مصدر التزويد بالتيار الكهربائي عن بعد قبل إجراء الصيانة.	 WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.
تحذير القطع المتحركة. لا تقم بتشغيل الوحدة عند إزالة الشبكة. أوقف تشغيل الوحدة قبل إجراء الصيانة.	 WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.
تنبيه الأجزاء ذات درجة حرارة عالية. قد تصاب بحرق عند إزالة هذه اللوحة.	 CAUTION High temperature parts. You might get burned when removing this panel.
تنبيه لا تلمس أجنحة الألومنيوم الخاصة بالوحدة. يؤدي القيام بذلك إلى حدوث إصابة.	 CAUTION Do not touch the aluminum fins of the unit. Doing so may result in injury.
تنبيه خطر الانفجار افتح صمامات الصيانة قبل التشغيل، وإلا قد يحدث انفجار.	 CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.

١ احتياطات السلامة

لا تتحمل الجهة المصنعة أية مسؤولية عن التلف الناتج عن عدم مراعاة الوصف الوارد في هذا الدليل.

⚠ تحذير

عام

- قبل بدء تركيب مكيف الهواء، يرجى قراءة دليل التركيب بعناية، اتباع التعليمات الواردة فيه لتركيب مكيف الهواء.
- لا يسمح سوى لأخصائي تركيب مؤهل أو فني صيانة مؤهل بإجراء أعمال التركيب. قد يؤدي التركيب غير المناسب إلى تسرب مياه أو حدوث صدمة كهربائية أو حريق.
- لا تستخدم أي غاز تبريد مختلف عن الغاز المحدد للإكمال أو الاستبدال. وإلا، فقد ينشأ ضغط عالٍ بشكل غير طبيعي في دورة التبريد، الأمر الذي قد ينجم عنه تعطل المنتج أو انفجاره أو التعرض لإصابة جسدية.
- قبل فتح اللوحة الأمامية للوحدة الداخلية أو لوحة الصيانة للوحدة الخارجية، اضبط قاطع الدائرة على وضع OFF (إيقاف). فقد يؤدي عدم ضبط قاطع الدائرة على وضع OFF (إيقاف) إلى صدمة كهربائية من خلال التلامس مع الأجزاء الداخلية. لا يسمح سوى لأخصائي تركيب مؤهل (*1) أو فني صيانة مؤهل (*1) بإزالة اللوحة الأمامية للوحدة الداخلية أو لوحة الصيانة للوحدة الخارجية والقيام بالعمل المطلوب.
- قبل إجراء أعمال التركيب، أو الصيانة، أو الإصلاح، أو الفك، اضبط قاطع الدائرة على وضع OFF (إيقاف).
- وإلا فقد يتسبب ذلك في صدمات كهربائية.
- ضع علامة "جاري العمل" بالقرب من قاطع الدائرة أثناء إجراء أعمال التركيب، أو الصيانة، أو الإصلاح، أو الفك. هناك خطر حدوث صدمات كهربائية إذا تم ضبط قاطع الدائرة على وضع ON (تشغيل) بالخطأ.
- لا يسمح سوى لأخصائي تركيب مؤهل (*1) أو فني صيانة مؤهل بتنفيذ الأعمال في الأماكن (*1) المرتفعة باستخدام حامل طوله ٥٠ سم أو أطول، لفك شبكة دخول الهواء للوحدة الداخلية للقيام بالعمل المطلوب.
- ارتدي القفازات الواقية وملابس السلامة خلال التركيب والصيانة والفك.
- لا تلمس أجنحة الألومنيوم الخاصة بالوحدة. قد تجرح نفسك إذا قمت بذلك. إذا كان ولا بد من لمس الجناح لسبب ما، ارتدي أولاً القفازات الواقية وملابس السلامة، ومن ثم امضي قدماً.
- قبل فتح الشفط الهواء، اضبط قاطع الدائرة على وضع OFF (إيقاف). فقد يؤدي عدم ضبط قاطع الدائرة على وضع OFF (إيقاف) إلى إصابة من خلال التلامس مع الأجزاء الدوارة.
- لا يسمح سوى لأخصائي تركيب مؤهل (*1) أو فني صيانة مؤهل (*1) بإزالة الشفط الهواء والقيام بالعمل المطلوب.
- عند تنفيذ أعمال على ارتفاعات، استخدم سلم تتماشى مع معيار ISO 14122 واتبع الإجراء الواردة في تعليمات السلم. ارتدي أيضاً خوذة التي تستخدم في الصناعة لملابس واقية للعمل.

شكراً لك لشرائك مكيف الهواء توشيبا هذا.

يرجى قراءة هذا الدليل بعناية حيث أنها تحتوي على معلومات تتوافق مع توجيه الألات (Directive 2006/42/EC)، وتؤكد من فهمها. بعد الانتهاء من أعمال التركيب، قم بتسليم دليل التركيب هذا بالإضافة إلى دليل المالك إلى المستخدم، واطلب من المستخدم حفظهما في مكان آمن للرجوع إليهما في المستقبل.

التسمية العامة: مكيف هواء

تعريف أخصائي التركيب المؤهل أو فني الصيانة المؤهل

يجب أن يتم تركيب مكيف الهواء وصيانته وإصلاحه وإزالته من قبل أخصائي تركيب مؤهل أو فني صيانة مؤهل. عند الشروع في القيام بأي من هذه الوظائف، اطلب أخصائي تركيب مؤهل أو فني صيانة مؤهل للقيام بها. أخصائي التركيب المؤهل أو فني الصيانة المؤهل هو وكيل لديه مؤهلات ومعرفة على النحو الموضح في الجدول أدناه.

الوكيل	المؤهلات والمعارف التي يجب أن تكون لدى الوكيل
أخصائي التركيب المؤهل	<ul style="list-style-type: none"> أخصائي التركيب المؤهل هو الشخص الذي يقوم بتركيب وصيانة ونقل وإزالة مكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation. وقد تم تدريبه على تركيب وصيانة ونقل وإزالة مكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation، أو، بدلا من ذلك، صدرت إليه تعليمات للقيام بهذه العمليات من قبل فرد أو أفراد تم تدريبهم، وبالتالي لديهم المعرفة التامة المتعلقة بهذه العمليات. أخصائي التركيب المؤهل المسموح له بالقيام بهذه الأعمال الكهربائية المتضمنة في التركيب، والنقل، والإزالة لديه المؤهلات المتعلقة بهذا الأعمال الكهربائية على النحو المنصوص عليه في القوانين واللوائح المحلية، وهو الشخص الذي تم تدريبه على المسائل المتعلقة بالأعمال الكهربائية الخاصة بمكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation، أو، بدلا من ذلك، صدرت إليه تعليمات بمثل هذه الأمور من قبل فرد أو أفراد تم تدريبهم، وبالتالي لديه معرفة تامة ذات الصلة بهذا العمل. أخصائي التركيب المؤهل المسموح له بالقيام بهذه الأعمال الكهربائية المتضمنة في التركيب، والنقل، والإزالة لديه المؤهلات المتعلقة بهذا الأعمال الكهربائية الخاصة بمكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation، وهو الشخص الذي تم تدريبه على المسائل المتعلقة بالأعمال الكهربائية الخاصة بمكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation، أو، بدلا من ذلك، صدرت إليه تعليمات بمثل هذه الأمور من قبل فرد أو أفراد تم تدريبهم، وبالتالي لديه المعرفة التامة المتعلقة بهذا العمل. يتم تدريب أخصائي التركيب المؤهل المسموح له بالعمل في المرتفعات على الأمور المتعلقة بالعمل في المرتفعات مع مكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation، أو، بدلا من ذلك، صدرت إليه تعليمات للقيام بهذه الأمور من قبل فرد أو أفراد تم تدريبهم، وبالتالي لديه المعرفة التامة المتعلقة بهذا العمل.
فني الصيانة المؤهل	<ul style="list-style-type: none"> فني الصيانة المؤهل هو الشخص الذي يقوم بتركيب وإصلاح وصيانة ونقل وإزالة مكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation. وقد تم تدريبه على تركيب وإصلاح وصيانة ونقل وإزالة مكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation، أو، بدلا من ذلك، صدرت إليه تعليمات للقيام بهذه العمليات من قبل فرد أو أفراد تم تدريبهم، وبالتالي لديه المعرفة التامة المتعلقة بهذه العمليات. فني الصيانة المؤهل المسموح له بالقيام بهذه الأعمال الكهربائية المتضمنة في التركيب، والنقل، والإزالة لديه المؤهلات المتعلقة بهذا الأعمال الكهربائية على النحو المنصوص عليه في القوانين واللوائح المحلية، وهو الشخص الذي تم تدريبه على المسائل المتعلقة بالأعمال الكهربائية الخاصة بمكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation، أو، بدلا من ذلك، صدرت إليه تعليمات بمثل هذه الأمور من قبل فرد أو أفراد تم تدريبهم، وبالتالي لديه معرفة تامة ذات الصلة بهذا العمل. فني الصيانة المؤهل المسموح له بالقيام بهذه الأعمال الكهربائية المتضمنة في التركيب، والإصلاح، والنقل، والإزالة لديه المؤهلات المتعلقة بهذا الأعمال الكهربائية على النحو المنصوص عليه في القوانين واللوائح المحلية، وهو الشخص الذي تم تدريبه على المسائل المتعلقة بالأعمال الكهربائية الخاصة بمكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation، أو، بدلا من ذلك، صدرت إليه تعليمات بمثل هذه الأمور من قبل فرد أو أفراد تم تدريبهم، وبالتالي لديه المعرفة التامة المتعلقة بهذا العمل. يتم تدريب فني الصيانة المؤهل المسموح له بالعمل في المرتفعات على الأمور المتعلقة بالعمل في المرتفعات مع مكيفات الهواء التي تصنعها شركة Toshiba Carrier Corporation، أو، بدلا من ذلك، صدرت إليه تعليمات للقيام بهذه الأمور من قبل فرد أو أفراد تم تدريبهم، وبالتالي لديه المعرفة التامة المتعلقة بهذا العمل.

تعريف ملابس الوقاية

عند نقل أو تركيب أو صيانة أو إصلاح أو فك مكيف الهواء، ارتد قفازات واقية وملابس "سلامة". وبالإضافة إلى الملابس الواقية العادية هذه، ارتدي الملابس الواقية الموصوفة أدناه عند القيام بالعمل الخاص المفصل في الجدول التالي. إن عدم ارتداء الملابس الواقية المناسبة أمر خطير لأنك سوف تكون أكثر عرضة للإصابة، والحروق، والصدمات الكهربائية والإصابات الأخرى.

الملابس الواقية المرتدية	العمل الذي يجري القيام به
القفازات الواقية ملابس "السلامة"	جميع أنواع العمل
تمنح القفازات حماية لفني الكهرباء وتحمي من الحرارة الحذاء العازل تمنح الملابس حماية من الصدمة الكهربائية	الأعمال المتعلقة بالكهرباء
خوذات للاستخدام أثناء التركيب	الأعمال التي تجرى على المرتفعات (٥٠ سم أو أكثر)
أحذية بها غطاء أصابع واقية إضافي	نقل أشياء ثقيلة
تمنح القفازات حماية لفني الكهرباء وتحمي من الحرارة	إصلاح الوحدة الخارجية


احتياطات السلامة هذه تصف الأمور المهمة المتعلقة بالسلامة لمنع إصابة المستخدمين أو غيرهم ولمنع الحاق الأضرار بالململكات. يرجى قراءة هذا الدليل بعد فهم المحتويات أدناه (معاني العلامات)، والتأكد من اتباع الوصف.

التوضيح	معاني العلامات
 تحذير	يشير النص الذي تم تمييزه بالطريقة إلى أن عدم الالتزام بالتعليمات الواردة في التحذير قد يؤدي إلى أذى بدني خطير (1*) أو الوفاة إذا تم التعامل مع المنتج بشكل غير سليم.
 تنبيه	يشير النص الذي تم تمييزه بالطريقة إلى أن عدم الالتزام بالتعليمات الواردة في التنبيه قد يؤدي إلى إصابة طفيفة (2*) أو ضرر بسيط (3*) يلحق بالململكات إذا تم التعامل مع المنتج بشكل غير سليم.

- 1*: يشير الأذى البدني الخطير إلى فقدان البصر، والإصابة، والحروق، والصدمات الكهربائية، وكسر العظام، والتسمم، والإصابات الأخرى التي تترك أثرا وتتطلب علاج في المستشفى أو علاج طويل الأجل خارج المستشفى.
- 2*: تشير الإصابة الطفيفة إلى الإصابات، والحروق، والصدمات الكهربائية، والإصابات الأخرى التي لا تتطلب علاج في المستشفى أو علاج طويل خارج المستشفى.
- 3*: يشير الضرر الذي يلحق بالململكات إلى الضرر الذي يلحق بالمباني، والأثاث والأجهزة المنزلية، والماشية المحلية، والحيوانات الأليفة.

مركز الجاذبية

(الوحدة: مم)



يُف تعار وأ شرنو دختساو، اوها فيكمي، تدحو لمحل تيكرش تعطار دختسا امهبيكرت.

المحتويات

١	احتياطات السلامة.....	٣
٢	إجراء الملحقات.....	٦
٣	اختيار مكان التركيب.....	٦
٤	التركيب.....	٨
٥	أنابيب التصريف.....	٩
٦	تصميم القنوات.....	١١
٧	شبكة أنابيب سائل التبريد.....	١٢
٨	التوصيلات الكهربائية.....	١٤
٩	الضوابط القابلة للتطبيق.....	١٦
١٠	التشغيل التجريبي.....	٢١
١١	الصيانة.....	٢١
١٢	التحري عن الخلل وإصلاحه.....	٢٢

التعليمات الأصلية

- يرجى قراءة دليل التركيب بعناية قبل تركيب مكيف الهواء.
- يصف هذا الدليل طريق تركيب الوحدة الداخلية.
 - لتركيب الوحدة الخارجية، اتبع دليل التركيب مرفق مع الوحدة الخارجية.
 - للاحتياطات اللازمة للسلامة، اتبع دليل التنبيه المرفق بالوحدة الخارجية.

اعتماد غاز التبريد الجديد

يستخدم مكيف الهواء هذا سائل R410A، وهو غاز تبريد صديق للبيئة.



1116950172



TOSHIBA

مكيف هواء (طراز سبلت)
دليل التركيب

للاستخدام التجاري فقط

الوحدة الداخلية

اسم الطراز:

رباعي الاتجاه نوع كاسيت

RAV-SH6001BP Series
RAV-SH6001BTP Series

